
Home & Kitchen

Stoves & Electric Fireplace
40 IN



(24/7):service@kmcgloble-us.com
(USA) +1 213-816-4788

IMPORTANT SAFETY INFORMATION!

WARNING

- **ALWAYS** keep **electric cords**, **home furnishings**, **drapes**, **clothing**, **papers**, or **other combustibles** at least **3 feet (0.9m) away from the front of this heater**, and away from the bottom, sides, and rear of this heater.
- **DO NOT** place the heater near a bed because objects such as pillows or blankets can fall off the bed and be ignited by the heater.
- **DO NOT COVER** this heater or **block** the air vents at all. Doing so could cause a **fire.**
- **AVOID fire or electric shock! NEVER** insert or allow any foreign objects to enter the ventilation or exhaust openings of this heater.
- **Prevent Fire!** Keep all **flammable liquids**, like gasoline or paint, away from this heater. This heater produces **arcing sparks** that **could ignite** flammable liquids.
- **DO NOT cover** this heater in any manner. Doing so could block the air flow and cause the unit to **overheat**, or could **ignite** the material covering the heater.
- **NEVER** run the **power cord** under carpet, rugs, runners, or any other covering. Doing so could cause the cord or materials covering the cord to overheat.
- **AVOID FIRE!** Regularly inspect all air vents to make sure they are free from dust, lint, or other blockage**. Unplug the unit** and clean with a **vacuum ONLY. DO NOT** rinse or get wet.

WARNING

- **For residential use only! NOT for commercial use! NEVER** use this fireplace for other than its intended purpose.
- **Only** use this insert with **the mantel that came with the insert. NEVER** use a mantel from **another manufacturer.**
- **NEVER use** this electric fireplace insert **unless** it is **properly installed** in the correct mantel.
- Use **extreme caution** if using this heater **near children**, or where children may be present.
- **NEVER** leave this heater unattended. **ALWAYS** unplug this heater when not in use.
- This heater is **hot** when **in use. AVOID INJURY! DO NOT TOUCH hot surfaces, or attempt to move this heater while it is hot.**
- **ALWAYS** turn this heater off before unplugging it from the outlet.
- **AVOID INJURY!** Keep the cord from crossing traffic areas to avoid tripping.
- **NEVER modify this fireplace**. Doing so could result in personal injury or property damage**.** Modification of this fireplace **completely voids all warranties.**
- **Discontinue use** if this fireplace **malfunctions** or is **dropped or damaged in any manner.**

WARNING

- **Risk of electric shock**! **DO NOT OPEN!** No user-serviceable parts inside!
- **ALWAYS disconnect** this unit from the **power** supply **before** performing any assembly or cleaning, or before relocating the electric fireplace.
- **ALWAYS** store this heater in a dry location**. NEVER** use the fireplace if it has become wet.
- **NEVER** use this heater in **bathrooms, laundry rooms**, or any other location where the heater could fall into a **bathtub** or **pool**, **become damp** or **come in contact with water.**
- **NEVER** hang this unit on a wall **directly below an electrical outlet.**
- **NEVER** operate this heater if the **power cord** or **plug** has become **damaged,** or if the **grounding pin** is **damaged** or **missing.**
- Place the heater near a wall outlet so an extension cord is not needed. If an extension cord is needed, the **gauge** of the cord **must be at least 14AWG,** and the **rating must be at least 1875 Watts**. **NEVER** use a **smaller gauge** cord with a **lower rating**. Doing so may result in **fire** or **electric shock.**
- **ONLY** use this heater on a **110-120 Volt 14 Amp grounded circuit. NEVER overload the circuit.** If this heater trips the circuit breaker, unplug all other appliances on the same circuit before the next use. Avoid plugging other appliances into the same circuit as this heater.
- **NEVER** plug this heater into an outlet that is **old**, **cracked**, or has any **loose wires or connections**. Plugging this heater into a faulty outlet could result in **electric arcing** within the outlet that could cause the **outlet** to **overheat or catch fire.**
- **ALWAYS** check your heater cord and plug connections with **each use**!
  - i) **MAKE SURE** the plug fits tight in the outlet! Faulty wall outlet connections or loose plugs can cause the outlet to overheat.
  - ii) **Heaters draw more current** than small appliances. **Overheating** may occur even if it has not occurred with the use of other appliances.
  - iii) During use **check frequently** to see if the **plug outlet or faceplate** is **HOT**!
  - iv) If the outlet or faceplate is **HOT**, **discontinue use immediately** and have a qualified electrician inspect and/or replace the faulty outlets.

PREPARATION

This insert has front panel made of **GLASS! ALWAYS** use **extreme caution** when handling **glass.** Failure to do so could result in **personal injury** or **property damage**

Remove all parts and hardware from the carton and place them on a clean, soft, dry surface. Check the parts list to make sure nothing is missing. Dispose of packaging materials properly. Please recycle whenever possible.

OPERATION

Read and understand this entire owner's manual, including **all safety information**, before **plugging in** or **using** this product. Failure to do so could result in **electric shock, fire, serious injury, or death.**

Power

Make sure the ON/OFF switch, located on the control panel, is in the OFF position. Plug the power cord into a **110-120V** Volt **14** Amp grounded outlet (see **IMPORTANT SAFETY INFORMATION** on **Pages 3 and 4**). Make sure the outlet is in good condition and that the plug is not loose. **NEVER** exceed the maximum amperage for the circuit. **DO NOT** plug other appliances into the same circuit.

Thermostat

This heater is equipped with a Thermostat. Should the ambient temperature exceeds/lower than the set temperature, the heater will automatically turn OFF/ON.


SPECIFICATIONS

Power Supply	**110-120V**
Rated Power	**1500W**

TOOLS REQUIRED



PHILLIPS SCREWDRIVER



DRILL & NO.6 DRILL BIT



PENCIL & RULER




2 AAA BATTERIES



LEVELER

PARTS&HARDWARE

A Fireplace




1PC

B 4x12mm Screws




16PCS

C Metal bracket




3PCS

D Clip




4PCS

E 3x10mm Screws




8PCS

F Remote control



1PC


G Strip Light



2 PCS

CONTROL PANEL AND REMOTE





Control panel/Remote control Operation

BUTTON	FUNCTION	ACTION&INDICATION
	1. Press once to turn on flame effect, fuel bed lights, and enable remote control functions. 2. Press again to turn off flame effect, and shut off power to remote control, and all functions	1. Flame effect and fuel bed turn on. Remote control functions are enabled. 2. Flame effect turn off. The remote control functions will not function.
	COLOR button: Makes the color flame effect changing.	1. Press once. Flame color effect get changing. Press again until desired setting is reached. Keep press 3 seconds Makes flame effect dimmer and brighter.Press again until desired setting is reached.
	HEATER button:Turn heater on and off.	1. Press once. Indicator lights up. Shows “00” no heater 2. Press again. Indicator lights up. Shows “HH”1400W heaters turns on and blows hot air. 3. Press again， set the temperature 65F-70F-75F-80F-85F-90F-95F-00-HH
	TIMER button: Control timer settings to turn off fireplace at selected time.	1. Press once. Indicator light turn on. Temperature is set to hours. Press again until desired setting is reached. LED display show setting.
 COLOR	LED backlight button: Turn on LED backlight and change color	1.LED backlight button: Turn on LED backlight and change color. 2.NOTE: This button only on remote.

NOTICE	To improve operation, **DO NOT press the buttons too quickly**. Give the unit time to respond to each command.

⚠ WARNING! **NEVER leave heater unattended during operation!** Failure to do so could result in **personal injury** or **property damage**.

NOTICE	When the heater is first turned on, a slight odor may be present. This is normal and should not occur again unless the heater is not used for a long period of time.

Remote Control Battery Information

- Small remote control uses two AAA battery(not included)



NEVER dispose of batteries in fire. Failure to observe this precaution may result in an explosion. Dispose of batteries at your local hazardous material processing center.

CARE AND MAINTENANCE



ALWAYS turn the heater **OFF** and **unplug the power cord from the outlet** before cleaning, performing maintenance, or moving this fireplace. Failure to do so could result in **electric shock, fire, or personal injury.**

Cleaning



NEVER immerse in water or spray with water. Doing so could result in electric shock, fire, or personal injury.

Metal:

- Buff using a soft cloth, slightly dampened with a citrus oil-based product.
- **DO NOT** use brass polish or household cleaners as these products will damage the metal trim.

Glass:

- Use a good quality glass cleaner and dry thoroughly with a paper towel or lint-free cloth.
- **NEVER** use abrasive cleansers, liquid sprays, or any cleaner that could scratch the surface.

Vents:

- Use a vacuum or duster to remove dust and dirt from the heater and vent areas.
- Clean the exterior of the fireplace with a slightly damp cloth or duster.

Maintenance

Risk of electric shock! DO NOT OPEN! No user- serviceable parts inside!

ALWAYS turn the heater **OFF** and **unplug the power cord from the outlet** before cleaning, performing maintenance, or moving this fireplace. Failure to do so could result in **electric shock, fire, or personal injury**.

Electrical and Moving Parts:

- The fan motors are lubricated at the factory and will not require lubrication.
- Electrical components are integrated in the fireplace and are not serviceable by the consumer.


Storage:

- Store heater in a clean dry place when not in use.

WARNING! No other servicing should be performed by the consumer. Do not attempt to service the unit yourself.

INSTALLATION AND ASSEMBLY

1. Select a suitable location that is not susceptible to moisture.
2. Fix part A,B,C on the fireplace by 2 screws.(Fig A)
3 Fix the fireplace in the fireplace mantel by screws



TROUBLESHOOTING

WARNING: Turn off the appliance, unplug and let cool for at least 10 minutes before attempting to service. Only a qualified professional should attempt to service or repair the appliance.

Problem	Possible Cause	Corrective Action
No flame	1. Dimmer control button set too Low. 2. LED bulb are burned out. 3. “Flame wand” has come loose from bracket. 4. “Flame wand” motor is not functioning.	1.Push Dimmer button to increase light 2. Contact with the technical 3. Remove back panel. Secure end of “ flame wand” back into the support Bracket 4. Call of Technical service.
The appliance turns off and will not turn back on	1.The overheat protection device in the appliance has been triggered. 2. House circuit breaker has been tripped	1.Turn all controls off, unplug the appliance, allow to cool for at least 10 minutes, then plug back in and restart. 2. Reset house circuit breaker.
The appliance does not turn on when the button is pushed to “ON”	1.The overheat protection device in the appliance has been triggered.	1.Turn all controls off, unplug the appliance. Allow to cool for at least 10 minutes, then plug back in and restart.
Remote control does not work	1.Low batteries. 2. Manual control on the appliance must be “ON” before operating the remote control.	1. Replace all batteries in the remote control 2. Push the appliance “ON” using the manual control panel, then use remote control to operate. If using the remote control the appliance, you must also turn on the appliance “ON” using the remote control

WIFI Connection
Beginner's Guidebook

NO.1 Download App

You can download the App by searching "Tuya Smart"in mobile app stores or scanning the following QR code.

NO.2 Register/Log in/Forgot Password

NO.3 Use APP

NO.3.1 Home/Member Management

NO.3.2 Voice Assistant

NO.3.3 Environment Information


NO.3.4 Add Devices Click

NO.3.4.1 Add Manually-Wi-Fi Devices

Reset the device first

1. Plug in appliance. Turn on the standby switch first  As the product is powered on, the buzzer will beep into standby mode.

2. Hold  button for 5 Seconds, the led digital display will show P0 or P1. Then you can use your phone to connect it with WIFI.




NO.3.4.1 Add Manually - Wi-Fi Devices-Network Configuration

1 Download App

2 Search device -Auto Scan

3 Search device-Done

4 Conneect to Wi-Fi




NO.3.4.1 Add Manually - Wi-Fi Devices-Network Configuration

5 Cancel

6 Add Devices Click

7 Operating Interface



AFTER-SALE

AFTER-SALE SERVICE

If you have any suggestions or encounter quality issues with our products, please contact us first.

Our after-sales team will respond within 24 hours, and we will do our best to provide a solution until you are satisfied.

GUARANTEED CUSTOMER SERVICE

Your shopping experience is very important to us!

If you feel unsatisfied or have any questions,
just contact us!

If you want to share how wonderful our smart product makes your home, **just contact us** and share your pictures!

For further information,
just contact us!

service@kmcgloble-us.com

(USA) +1 213-816-4788