Side Button Function Description

	**Stop:** Press the "Stop" button to stop the current work.
	**Lady/Move:** Press to start Women Washing Function. During the cleaning process, press this button switch to "mobile cleaning" .
	Hip/Move : Press to start Hip Cleaning Function. During the cleaning process, press the button switch to"mobile cleaning".
	**Flush:** Press this button to start the toilet flushing function.
	**Dry:** Press to start Warm Air Drying function, and the drying heating part blows out hot air to dry the buttock with warm air.
	**Light:** Press this button to switch the night light and the atmosphere light.

■ Foot sensing

- When the lid and seat are closed, short touch the sensing area with foot and the lid automatically opens.
  When the lid and seat are closed, long touch the sensing area with foot and the lid and seat automatically open;
  When the lid open，seat closed, short touch the sensing area with foot and the seat automatically opens;
  When the lid and seat are open，short touch the sensing area with foot to realize the flushing function.

Remote Control Sync/Re-Pair

This remote is pre-synced with current smart toilet at the factory. Normally, no additional syncing is needed.

If the remote is not working, you can try to re-sync it using the method below:



Procedure:
1) Cycle the toilet's power.
2) Hold the Buttock Wash button on the smart toilet until its LED flashes.
3) Press any remote button to sync

Model: SM8004-1 or SM8004-2

Remote Function Description

The remote utilizes a dual-action press design for efcient control:
Shor Press: Instantly activates the primar function labeled on the button.
Long Press (hold for 3-5 seconds): Activates a secondary, extended function associated with that button.
One beep for off, two beeps for on.

