

INSTALLATION
Product Manual




IMPORTANT INFORMATION!

please read the entire manual before starting to assemble and/or using this product.follow the manual thoroughly and keep it for further reference.




AVOID SCRATCHES!

In order to avoid scratching this furnuture should be assembled on a soft layer-could be a rug.



IMPROVE EFFICIENCY !

Try to find a partner to install with you, which can speed up the installation efficiency and shorten the time.



ANTI-TOPPLE WARNING !


Overturned furniture can cause serious or fatal crush injuries. To prevent tipping over, be sure to use the wall attachment, if not included with this product. Please purchase the wall attachment that fit your wall. If unsure, seek professional advice. Please read and follow each step of the instructions carefully.

IMPORTANT !




It is important that any product which is assembled using any kind of screw is re-tightened 2 weeks after assembly,and once every 3 months - in order to assure stability through-out the lifespan of the product.

For regular maintenance and cleaning of the product, for the frame, please use a rag dipped in neutral detergent to fully wipe it, and then dry it with a clean rag.For glass materials, wipe with a rag dampened with water glass cleaner, and then dry with a dry rag.

Do not use an electric screwdriver, and do not use too much force when installing, because the board is easy to break.






Please prepare the following tools


















When installing, please carefully confirm whether each screw corresponds to the manual, accessories with similar shapes can be distinguished by size

A x 29	B x 29	C x 30	D x 8
			
CRA0635A	CRB1595A	CRF0830A	CRD0440A

E x 4	F x 24	G x 2	H x 2
			
DGA861C	CRD3514A		CRE0418A

J x 4	K x 28	L x 28	M x 1
			
∅4.9 x 16 mm	14 x 13 x 10 mm	CRD0316A	165 mm

N x 2




⚠WARNING






Children have died from furniture tipover.To reduce the risk of furniture tipover:




- ALWAYS install Anti-tip device provided.
- NEVER put a TV on this product.
- NEVER allow children to stand,climb or hang on drawers,doors,or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.


This is a permanent label.
Do not remove!




ASSEMBLED BY 2 ADULTS

1

C x 4	D x 4	
 CRF0830A	 CRD0440A	




Attach panel 2 and 3 to panel 1 using wooden dowel(C), and fix with screw(D) as shown.







2


Insert panel 5 along available grooves as shown.



3



C x 4	D x 4	
		
CRF0830A	CRD0440A	







Attach panel 6 to panel 2 and 3 using wooden dowel(C), and fix with screw(D) as shown.

4

A x 1	
	
CRA0635A	






Screw eccentric rod(A) into panel 9 at first.


5

B x 1



CRB1595A







Attach panel 13 to panel 9, add cam lock(B) into panel 13 and turn clockwise to tighten as shown.


6

A x 7




CRA0635A








Screw eccentric rod(A) into panel 12 at first.




7



B x 7	C x 6	
 CRB1595A	 CRF0830A	


Attach panel 8, 9 and 13 to panel 9 using wooden dowel(C), add cam lock(B) into panel 8,9,13 and turn clockwise to tighten
as shown.






8



A x 2	
 CRA0635A	




Screw eccentric rod(A) into panel 7 at first.




9

B x 2	C x 2	
 CRB1595A	 CRF0830A	


Attach panel 7 to panel 12 using wooden dowel(C), add cam lock(B) into panel 12 and turn clockwise to tighten as shown.






10

Insert panel 16 along available grooves as shown.





11


A x 17




CRA0635A








Screw eccentric rod(A) into panel 10 and 11 at first.






12

B x 9




CRB1595A


C x 8





CRF0830A





Attach panel 10 to panel 7, 8, 9 and 13 using wooden dowel(C), add cam lock(B) into and turn clockwise to tighten as shown.









13

B x 2	C x 2	
		
CRB1595A	CRF0830A	







Attach panel 10 to panel 6 using wooden dowel(C), add cam lock(B) into and turn clockwise to tighten as shown.


14

A x 2




CRA0635A





Screw eccentric rod(A) into panel 12 at first.





15

B x 2





CRB1595A







Insert panel 16 along available grooves as shown.
Attach panel 14 to panel 12, add cam lock(B) into and turn clockwise to tighten as shown.

16


B x 6	C x 4	
 CRB1595A	 CRF0830A	





Attach panel 11 to panel 6, 7 and 14 using wooden dowel(C), add cam lock(B) into and turn clockwise to tighten as shown.



17



J x 4	
 ∅4.9 x 16 mm	







Insert layer pin(J) into panel 2 and 3, then place shelf panel 4 on.

18

E x 4	F x 8	
 DGA861C	 CRD3514A	




Fix hinge(E) to panel 17 and 18 with screw(F) as shown.



19


F x 8	G x 1	H x 1	
CRD3514A		CRE0418A	



Aseemble door panel 17 to the unit by fixing hinge with screw(F) as shown.
Fix knob(G) with screw(H) as shown.

20


F x 8	G x 1	H x 1	
CRD3514A		CRE0418A	



Aseemble door panel 18 to the unit by fixing hinge with screw(F) as shown.
Fix knob(G) with screw(H) as shown.


21


M x 1





165 mm

Insert rod(M) into the unit.














22


K x 28	L x 28	
		
14 x 13 x 10 mm	CRD0316A	




Insert buckle(K) into back slots
and fix with screw(L) as shown.


23









1.




2.




3.





4.








24




















WARRANTY

WARRANTY CLAIMS

- There is a 30-day warranty for broken furniture or any other problems that do not work properly. The warranty will start from the date of purchase which must be verified by proof of purchase.

- Before making a claim, we may be able to answer your query, simply call us. Please leave your purchase order number, along with some details of the problem, if you want a replacement part. We will arrange within 48 hours. If there is out of stock, we will reply with a shipping date.

- The product must be used in accordance with the instructions provided. For health reasons.

- For other reasons, if the furniture needs to be returned, it must be cleaned and dried and operated within 30 days of receipt.

Type of Warranty Claim

- Failure to follow the furniture instructions will invalidate the warranty. Attention please.

- Does not include damage during installation, but includes damage during transportation.

Scope of responsibility

- Shall not bear any responsibility for misuse or user damage and / or loss of parts during the installation of furniture.

- After using, the damage and scratches of the furniture are not covered by the warranty.

The Warranty Relates to All Bought in The Us and Covers The Following Areas

- Sheet parts: 1 month from the date of purchase.

- Electrical parts: 1 month from the date of purchase.

RETURNS

CHANGED YOUR MIND AND NEED TO RETURN YOU ITEM?

PLEASE FOLLOW THE BELOW INSTRUCTIONS:

- If you have purchased and have simply changed your mind, follow the retailer's instructions for returns.

DEFECTIVE ITEMS

- If your item is defective in any way, i.e. it doesn't work but you can't identify why, in the first instance, please call us.

DAMAGED ITEMS

- If you receive an order with obvious shipping damage from the retailer, then we suggest the delivery is refused. If the delivery has been accepted and then shipping damage is found, please follow the specific instructions advised by the retailer.
  In all circumstances please save all packaging material and paperwork for the order.
  Please be aware that if you dispose of packaging material or attempt to return the merchandise without contacting the fulfiller, you jeopardise your chances of making a claim, and you may not receive a credit for the return.