
INSTALLATION
Product Manual

Version: 460067US-01-26A-CN




IMPORTANT INFORMATION!

please read the entire manual before starting to assemble and/or using this product.follow the manual thoroughly and keep it for further reference.




AVOID SCRATCHES!

In order to avoid scratching this furnuture should be assembled on a soft layer-could be a rug.



IMPROVE EFFICIENCY !

Try to find a partner to install with you, which can speed up the installation efficiency and shorten the time.



ANTI-TOPPLE WARNING !


Overturned furniture can cause serious or fatal crush injuries. To prevent tipping over, be sure to use the wall attachment, if not included with this product. Please purchase the wall attachment that fit your wall. If unsure, seek professional advice. Please read and follow each step of the instructions carefully.

IMPORTANT !

It is important that any product which is assembled using any kind of screw is re-tightened 2 weeks after assembly,and once every 3 months - in order to assure stability through-out the lifespan of the product.





For regular maintenance and cleaning of the product, for the frame, please use a rag dipped in neutral detergent to fully wipe it, and then dry it with a clean rag.For glass materials, wipe with a rag dampened with water glass cleaner, and then dry with a dry rag.



Do not use an electric screwdriver, and do not use too much force when installing, because the board is easy to break.









When installing, please carefully confirm whether each screw corresponds to the manual, accessories with similar shapes can be distinguished by size

A x 84	B x 102	C x 60	D x 26	E x 96
				
∅7 x 35 mm	∅15 x 9.5 mm	∅8 x 30 mm	∅5 x 40 mm	∅3.5 x 12 mm

F x 8	G x 8	H x 8	I x 4	J x 8
				
∅5 x 16 mm		20 x 15 x 1.5 mm	∅5 x 60 mm	

K x 4	L x 4	M x 2	N x 64	O x 14
				
M4 x 19 mm	M4 x 9 mm	M-1 M-2	∅21 mm	

P x 32	R x 4	x 64
		
	∅21 mm	CL DL CR DR




⚠WARNING

Children have died from furniture tipover.To reduce the risk of furniture tipover:


- ALWAYS install Anti-tip device provided.
- NEVER put a TV on this product.
- NEVER allow children to stand,climb or hang on drawers,doors,or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

This is a permanent label.
Do not remove!





1

A x 16





∅7 x 35 mm






Screw eccentric rod (A) onto plates 1 and 23.






2


D x 16



∅5 x 40 mm




Secure plates 2 and 3 to plate 4 using screw (D).



3

Insert plate 5 into the available slots.




x4


4

B x 8




∅15 x 9.5 mm





Connect plate 1 to plates 2 and 3, then tighten by turning eccentric wheel (B) clockwise.





5

B x 8




∅15 x 9.5 mm






Connect plate 23 to plates 2 and 3, then tighten by turning eccentric wheel (B) clockwise.




6

J x 4	L x 4 M4 x 9 mm	



x2



x2

Secure knob (J) to plates 1 and 23 using screw (L).


7


E x 16




∅3.5 x 12 mm

x 4











Secure slide rail (DR) and (DL) to plates 3 and 2, respectively using screw (E).




x2



x2


8


A x 8	B x 4	C x 2	I x 2	
∅7 x 35 mm	∅15 x 9.5 mm	∅8 x 30 mm	∅5 x 60 mm	




Screw eccentric rod (A) onto plates 6 and 7.
Connect plates 6 and 7 using wooden dowel (C) and double-ended screw (I), then tighten by turning eccentric wheel (B) clockwise.

9







Secure part (M-2) to plates 6 and 7 using screw (M-1).



10

E x 4	H x 4	
		
∅3.5 x 12 mm	20 x 15 x 1.5 mm	




Secure bracket (H) to both sides of plate 12 using screw (E).


11

E x 4






∅3.5 x 12 mm







Secure plate 12 to plates 6 and 7 using screw (E).


12

A x 4	E x 8	x 2	
			
∅7 x 35 mm	∅3.5 x 12 mm	CR CL	



Screw eccentric rod (A) onto plates 10 and 14. Secure slide rail (CR) and (CL) to plates 14 and 10 using screw (E).









13


E x 8	x 2	
 ∅3.5 x 12 mm	 CR CL	


Secure slide rail (CR) to plate 13 using screw (E).
Flip the same board to other side, secure slide rail (CL) .






- Please note that the hole positions of the screws on these two slide rails are different.






Flip



14


E x 4	H x 4	
∅3.5 x 12 mm	20 x 15 x 1.5 mm	




Secure bracket (H) to both sides of plate 13 using screw (E).


15


A x 2



∅7 x 35 mm










Screw eccentric rod (A) onto plate 11.




16


B x 4	C x 4	
		
∅15 x 9.5 mm	∅8 x 30 mm	



Connect plates 10 and 14 to plate 11 using wooden dowel (C), then tighten by turning eccentric wheel (B) clockwise.



17


B x 4	C x 6	D x 2	
			
∅15 x 9.5 mm	∅8 x 30 mm	∅5 x 40 mm	




Connect plates 10 and 14 to plates 6 and 7 using wooden dowel (C), then tighten by turning eccentric wheel (B) clockwise.
Secure plate 11 to plate 12 using screw (D).

18



B x 2	C x 2	
		
∅15 x 9.5 mm	∅8 x 30 mm	






Connect plate 13 to plate 11 using wooden dowel (C), then tighten by turning eccentric wheel (B) clockwise.


19

B x 4	C x 4	
		
∅15 x 9.5 mm	∅8 x 30 mm	






Connect plate 15 to plate 7 and plate 8 to plate 6 using wooden dowel (C), then tighten by turning eccentric wheel (B) clockwise.


20




Insert plates 24 and 25 into the available slots.

21

B x 4	C x 2	I x 2	
			
∅15 x 9.5 mm	∅8 x 30 mm	∅5 x 60 mm	







Connect plates 16 and 17 using wooden dowel (C) and double-ended screw (I), then tighten by turning eccentric wheel (B) clockwise.


22


A x 18



∅7 x 35 mm












Screw eccentric rod (A) onto plates 16 and 17.

23

C x 8	D x 8	E x 4	
			
∅8 x 30 mm	∅5 x 40 mm	∅3.5 x 12 mm	







Connect plates 16 and 17 to plates 8, 10, 14, and 15 using wooden dowel (C), and secure them with screw (D).
Secure bracket (H) to plate 16 and 17 using screw (E).


24


A x 12



∅7 x 35 mm








Screw eccentric rod (A) onto plates 18 and 19.

25



B x 12	C x 12	O x 14	
∅15 x 9.5 mm	∅8 x 30 mm		




x2


Connect plates 18 and 19 to plate 20 using wooden dowel (C), then tighten by turning eccentric wheel (B) clockwise.
Install part (O) on plates 18, 19, and 20.

26

B x 18	C x 20	
		
∅15 x 9.5 mm	∅8 x 30 mm	



Connect plates 18, 19, and 20 to plates 16 and 17 using wooden dowel (C), then tighten by turning eccentric wheel (B) clockwise.




27

F x 8




∅5 x 16 mm


Install pin (F) onto plates 8, 10, 14, and 15.
Then place plate 9 on top.




28

P x 32








Insert clip (P) into back slots, then secure them using screw (P).




29

E x 16	G x 8	
 ∅3.5 x 12 mm		

Secure hinge (G) to plates 21 and 22 using screw (E).





x2



x2

30

J x 4	K x 4	
	 M4 x 19 mm	




Secure knob (J) to plates 21 and 22 using screw (K).


31

E x 32



∅3.5 x 12 mm







Secure plate 21 to plates 8 and 14 via hinges.
Secure plate 22 to plates 10 and 15 via hinges.


32

N x 64	R x 4	
		


Install the drawers.
Attach part (N) to the eccentric wheel holes on drawer side plates 2 and 3.
Attach part (R) to the eccentric wheel holes on the plates of the same color.









33



If the door panels are not aligned, please adjust the screws on the hinges according to the illustration.



Or you can search this link to view the teaching video.
https://youtu.be/n0Lb36SoODM



WARRANTY

WARRANTY CLAIMS

- There is a 30-day warranty for broken furniture or any other problems that do not work properly. The warranty will start from the date of purchase which must be verified by proof of purchase.

- Before making a claim, we may be able to answer your query, simply call us. Please leave your purchase order number, along with some details of the problem, if you want a replacement part. We will arrange within 48 hours. If there is out of stock, we will reply with a shipping date.

- The product must be used in accordance with the instructions provided. For health reasons.

- For other reasons, if the furniture needs to be returned, it must be cleaned and dried and operated within 30 days of receipt.

Type of Warranty Claim

- Failure to follow the furniture instructions will invalidate the warranty. Attention please.

- Does not include damage during installation, but includes damage during transportation.

Scope of responsibility

- Shall not bear any responsibility for misuse or user damage and / or loss of parts during the installation of furniture.

- After using, the damage and scratches of the furniture are not covered by the warranty.

The Warranty Relates to All Bought in The Us and Covers The Following Areas

- Sheet parts: 1 month from the date of purchase.

- Electrical parts: 1 month from the date of purchase.

RETURNS

CHANGED YOUR MIND AND NEED TO RETURN YOU ITEM?

PLEASE FOLLOW THE BELOW INSTRUCTIONS:

•If you have purchased and have simply changed your mind, follow the retailer's instructions for returns.

DEFECTIVE ITEMS

•If your item is defective in any way, i.e. it doesn't work but you can't identify why, in the first instance, please call us.

DAMAGED ITEMS

•If you receive an order with obvious shipping damage from the retailer, then we suggest the delivery is refused. If the delivery has been accepted and then shipping damage is found, please follow the specific instructions advised by the retailer.
In all circumstances please save all packaging material and paperwork for the order. Please be aware that if you dispose of packaging material or attempt to return the merchandise without contacting the fulfiller, you jeopardise your chances of making a claim, and you may not receive a credit for the return.

AFTER-SALES CONTACT


adelahu@fufugaga.com


208-820-0068