
INSTALLATION
Product Manual




IMPORTANT INFORMATION!

Please read the entire manual before starting to assemble and/or using this product. Follow the manual thoroughly and keep it for further reference.




AVOID SCRATCHES!

In order to avoid scratching this furnuture should be assembled on a soft layer-could be a rug.



IMPROVE EFFICIENCY !

Try to find a partner to install with you, which can speed up the installation efficiency and shorten the time.



ANTI-TOPPLE WARNING !


Overturned furniture can cause serious or fatal crush injuries. To prevent tipping over, be sure to use the wall attachment, if not included with this product. Please purchase the wall attachment that fit your wall. If unsure, seek professional advice. Please read and follow each step of the instructions carefully.

IMPORTANT !

It is important that any product which is assembled using any kind of screw is re-tightened 2 weeks after assembly,and once every 3 months - in order to assure stability through-out the lifespan of the product.





For regular maintenance and cleaning of the product, for the frame, please use a rag dipped in neutral detergent to fully wipe it, and then dry it with a clean rag.For glass materials, wipe with a rag dampened with water glass cleaner, and then dry with a dry rag.





Do not use an electric screwdriver, and do not use too much force when installing, because the board is easy to break.











When installing, please carefully confirm whether each screw corresponds to the manual, accessories with similar shapes can be distinguished by size

A x 21+2	B x 46+4	C x 1	D x 2	E x 14+1
				
∅4 x 35 mm	∅7 x 50 mm	M4 mm		∅8 x 30 mm


F x 101+4	G x 101+4	H x 98+4	J x 8	K x 16+2
				
∅6 x 35 mm	∅15 x 9 mm	∅6 x 30 mm		∅5 x 25 mm

L x 48+4	M x 4	N x 4+1	O x 4+1	P x 40+4
				
∅4 x 14 mm		∅4 x 18 mm		

Q x 56+4	R x 2	S x 1			
		S-1	S-2	S-3	S-4
					
∅3 x 14 mm		x2	x2	x2	x2
			∅4 x 12 mm	∅6 x 30 mm	∅4 x 35 mm

T x 56+4

∅20 mm



⚠WARNING




















Children have died from furniture tipover.To reduce the risk of furniture tipover:



















- ALWAYS install Anti-tip device provided.
- NEVER put a TV on this product.
- NEVER allow children to stand,climb or hang on drawers,doors,or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

This is a permanent label.
Do not remove!




ASSEMBLED BY 2 ADULTS

1 x7 	2 x1 	3 x1 	4 x1 
5 x1 	6 x1 	7 x1 	8 x1 
9 x1 	10 x1 	11 x1 	12 x8 
13 x4 	14 x2 	15 x1 	16 x2 
17 x2 	18 x2 	19 x1 	20 x1 


21 x1 	22 x1 	23 x1 	24 x1 
25 x1 	26 x1 	27 x2 	28 x3 
29 x1 	30 x2 	31 x2 	32 x2 
33 x2 	34 x2 	35 x1 	36 x4 
37 x2 	38 x2 		


1

F x 4





∅6 x 35 mm





Screw eccentric rod (F) onto panels 23 and 24.







2

G x 4




∅15 x 9 mm






Connect panels 23 and 24 to panel 29, then tighten by turning eccentric wheel (G) clockwise.




3

Slide panel 38 along the available grooves.





4

F x 11




∅6 x 35 mm








Screw eccentric rod (F) onto panel 26.




5

B x 10	C x 1	H x 10	
			
∅7 x 50 mm	M4 mm	∅6 x 30 mm	




Connect panels 21, 22, 23, 24, and 25 to panel 26 using dowel (H), then secure them with screw (B).





6

F x 12




∅6 x 35 mm





Screw eccentric rod (F) onto panel 27.





7

G x 12




∅15 x 9 mm





Connect panel 27 to panel 28, then tighten by turning eccentric wheel (G) clockwise.





8

G x 11




∅15 x 9 mm







Connect the component to panel 26, then tighten by turning eccentric wheel (G) clockwise.



9


O x 4	Q x 8	
	 ∅3 x 14 mm	

Slide panels 37 and 38 along the available grooves.
Secure part (O) to panels 23, 25, and 24.





10

F x 9




∅6 x 35 mm








Screw eccentric rod (F) onto panel 9.




11

G x 9	H x 9	
		
∅15 x 9 mm	∅6 x 30 mm	




Connect panel 9 to panel 12 and 14 using dowel (H), then tighten by turning eccentric wheel (G) clockwise.





12

F x 18




∅6 x 35 mm








Screw eccentric rod (F) onto **both sides of** panel 11.




13



G x 9	H x 9	
		
∅15 x 9 mm	∅6 x 30 mm	




Connect panel 11 to the assembly unit using dowel (H), then tighten by turning eccentric wheel (G) clockwise.




14

G x 8	H x 8	
		
∅15 x 9 mm	∅6 x 30 mm	




Connect panel 13 to panel 11 using dowel (H), then tighten by turning eccentric wheel (G) clockwise.




15

Slide panel 36 along the available grooves.





16

F x 18




∅6 x 35 mm








Screw eccentric rod (F) onto **both sides of** panel 10.




17



G x 10	H x 10	
		
∅15 x 9 mm	∅6 x 30 mm	




Connect panel 10 to panels 11, 13, and 15 using dowel (H), then tighten by turning eccentric wheel (G) clockwise.




18

G x 9	H x 9	
		
∅15 x 9 mm	∅6 x 30 mm	




Connect panels 12 and 14 panel 10 using dowel (H), then tighten by turning eccentric wheel (G) clockwise.





19

F x 9




∅6 x 35 mm








Screw eccentric rod (F) onto panel 8.




20

G x 9	H x 9	
		
∅15 x 9 mm	∅6 x 30 mm	




Connect panel 8 to panels 12 and 14 using dowel (H), then tighten by turning eccentric wheel (G) clockwise.




21

Slide panel 35 along the available grooves.





22

F x 10




∅6 x 35 mm








Screw eccentric rod (F) onto panel 4.




23


A x 9	H x 8	
		
∅4 x 35 mm	∅6 x 30 mm	




Connect panel 4 to panels 5, 6, and 7 using dowel (H), then secure them with screw (A).





24


Q x 8	R x 2	
 ∅3 x 14 mm		

Secure angle bracket (R) to panel 6, 5, and 7 using screw (Q).




25

G x 10	H x 8	
		
∅15 x 9 mm	∅6 x 30 mm	




Connect the component to panels 8, 19, 15, 11, and 9 using dowel (H), then tighten by turning eccentric wheel (G) clockwise.




26

Slide panels 34 and 36 along the grooves.





27

F x 10




∅6 x 35 mm








Screw eccentric rod (F) onto panel 20.




28

B x 8	C x 1	H x 8	
			
∅7 x 50 mm	M4 mm	∅6 x 30 mm	




Connect panel 20 to the assembly unit using dowel (H), then secure them with screw (B).




29


A x 4



∅4 x 35 mm




Insert both ends of round tube 19 into part 17; secure part 17 to panels 10 and 11 using screw (A).




30


A x 4





∅4 x 35 mm




Insert both ends of round tube 18 into parts 16 and 17; secure part 16 to panels 8 and 9 using screw (A).




31


G x 10	H x 10	
		
∅15 x 9 mm	∅6 x 30 mm	




Connect the two assembled components using dowel (H), then tighten by turning eccentric wheel (G) clockwise.



32


P x 40	Q x 40	
	 ∅3 x 14 mm	

Insert clip (P) into the back slots and secure them using screw (Q).




33

K x 16





∅5 x 25 mm


Insert shelf pin (K) into panels 21, 22, 23, 24, 25 and place panels 32 and 33 on them.




34

J x 8	L x 16	
	 ∅4 x 14 mm	


Secure hinge (J) to panels 30 and 31 using screw (L).




35


L x 32	M x 4	N x 4	
			
∅4 x 14 mm		∅4 x 18 mm	

Secure panels 30 and 31 to the unit via the hinges using screw (L).
Secure knob (M) using screw (N).




36


B x 28	C x 1	E x 14	
			
∅7 x 50 mm	M4 mm	∅8 x 30 mm	




Connect panel 1 to panels 2 and 3 using dowel (E), and secure them with screw (B).



37


A x 4	D x 2	
 ∅4 x 35 mm		

Secure part (D) to panels 2 and 3 using screw (A).



38

You may lean a ladder against the round tubes of the cabinet.




39

T x 56

∅20 mm

Cover the holes with sticker (T).




40


S x 1

S-1 x2 | S-2 x2 | S-3 x2 | S-4 x2


Ø4 x 12 mm Ø6 x 30 mm Ø4 x 35 mm




Install the anti tip device as shown.




1.




2.




3.




4.





41





If the door panels are not aligned, please adjust the screws on the hinges according to the illustration.

















WARRANTY

WARRANTY CLAIMS

•There is a 30-day warranty for broken furniture or any other problems that do not work properly. The warranty will start from the date of purchase which must be verified by proof of purchase.

•Before making a claim, we may be able to answer your query, simply call us. Please leave your purchase order number, along with some details of the problem, if you want a replacement part. We will arrange within 48 hours. If there is out of stock, we will reply with a shipping date.

•The product must be used in accordance with the instructions provided. For health reasons.

•For other reasons, if the furniture needs to be returned, it must be cleaned and dried and operated within 30 days of receipt.

Type of Warranty Claim

•Failure to follow the furniture instructions will invalidate the warranty. Attention please.

•Does not include damage during installation, but includes damage during transportation.

Scope of responsibility

•Shall not bear any responsibility for misuse or user damage and / or loss of parts during the installation of furniture.

•After using, the damage and scratches of the furniture are not covered by the warranty.

The Warranty Relates to All Bought in The Us and Covers The Following Areas

•Sheet parts: 1 month from the date of purchase.

•Electrical parts: 1 month from the date of purchase.

RETURNS

CHANGED YOUR MIND AND NEED TO RETURN YOU ITEM?

PLEASE FOLLOW THE BELOW INSTRUCTIONS:

- If you have purchased and have simply changed your mind, follow the retailer's instructions for returns.

DEFECTIVE ITEMS

- If your item is defective in any way, i.e. it doesn't work but you can't identify why, in the first instance, please call us.

DAMAGED ITEMS

- If you receive an order with obvious shipping damage from the retailer, then we suggest the delivery is refused. If the delivery has been accepted and then shipping damage is found, please follow the specific instructions advised by the retailer.
  In all circumstances please save all packaging material and paperwork for the order. Please be aware that if you dispose of packaging material or attempt to return the merchandise without contacting the fulfiller, you jeopardise your chances of making a claim, and you may not receive a credit for the return.