

INSTALLATION
Product Manual

Version: 330162US-01-26A-XD




IMPORTANT INFORMATION!

please read the entire manual before starting to assemble and/or using this product.follow the manual thoroughly and keep it for further reference.




AVOID SCRATCHES!

In order to avoid scratching this furnuture should be assembled on a soft layer-could be a rug.



IMPROVE EFFICIENCY !

Try to find a partner to install with you, which can speed up the installation efficiency and shorten the time.



ANTI-TOPPLE WARNING !


Overturned furniture can cause serious or fatal crush injuries. To prevent tipping over, be sure to use the wall attachment, if not included with this product. Please purchase the wall attachment that fit your wall. If unsure, seek professional advice. Please read and follow each step of the instructions carefully.

IMPORTANT !

It is important that any product which is assembled using any kind of screw is re-tightened 2 weeks after assembly,and once every 3 months - in order to assure stability through-out the lifespan of the product.





For regular maintenance and cleaning of the product, for the frame, please use a rag dipped in neutral detergent to fully wipe it, and then dry it with a clean rag.For glass materials, wipe with a rag dampened with water glass cleaner, and then dry with a dry rag.





Do not use an electric screwdriver, and do not use too much force when installing, because the board is easy to break.













When installing, please carefully confirm whether each screw corresponds to the manual, accessories with similar shapes can be distinguished by size

A x 113+4	B x 113+4	C x 18+2	D x 164+4
			
∅6 x 35 mm	∅15 x 10 mm	∅6 x 30 mm	∅3.5 x 12 mm

E x 60+4	F x 12	G x 24+2	H x 1
			
∅4 x 35 mm			

J x 2	K x2+2	L x 2
		
	∅6 x 50 mm	

CL x 12	CR x 12	DL x 12	DR x 12
			



⚠WARNING







Children have died from furniture tipover.To reduce the risk of furniture tipover:

- ALWAYS install Anti-tip device provided.
- NEVER put a TV on this product.
- NEVER allow children to stand,climb or hang on drawers,doors,or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.


This is a permanent label.
Do not remove!




ASSEMBLED BY 2 ADULTS




x4



x4



x2



x2

⚠WARNING

































Children have died from furniture tipover.To reduce the risk of furniture tipover:

- ALWAYS install Anti-tip device provided.
- NEVER put a TV on this product.
- NEVER allow children to stand,climb or hang on drawers,doors,or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.




This is a permanent label.
Do not remove!




ASSEMBLED BY 2 ADULTS


1  1PC	2  2PCS	3  2PCS	4  2PCS
5  1PC	6  1PC	7  1PC	8  1PC
9  1PC	10  1PC	11  1PC	12  1PC
13  1PC	14  1PC	15  1PC	16  8PCS
17  8PCS	18  8PCS	19  12PCS	20  12PCS
21  4PCS	22  4PCS	23  4PCS	25  4PCS
26  4PCS	27  2PCS	28  2PCS	

1


A x 4	D x 36	CL x 6	CR x 6	
				
∅6 x 35 mm	∅3.5 x 12 mm			

Screw eccentric rod(A) into component 1. Place the left slide rail (CL) and right slide rail (CR) on component 1 and secure with screws (D).






Flip 180°, repeat the above steps





2


A x 6




∅6 x 35 mm








Screw eccentric rod(A) into components 2 and 3.





3

B x 3




∅15 x 10 mm





Connect components 1, 2, and 3 using the cam lock (B), turning the cam locks clockwise to tighten.





4

B x 3





∅15 x 10 mm









Connect components 1, 2, and 3 using the cam lock (B), turning the cam lock clockwise to tighten.






5




B x 4	K x 2	
		
∅15 x 10 mm	∅6 x 50 mm	




Insert the dowel (K) into components 1, and connect components 1, 4 using the cam lock (B), turning the cam lock clockwise to tighten.




6



A x 16	D x 36	CL x 6	CR x 6	
				
∅6 x 35 mm	∅3.5 x 12 mm			


Screw eccentric rod(A) into components 5 and 6.
Place the left slide rail (CL) and right slide rail (CR) on component 5 and 6, and secure with screws (D).






7




B x 8	C x 2	
		
∅15 x 10 mm	∅6 x 30 mm	




Insert the dowel (C) into components 5, connect 5 to 2, 3, and 4 using the cam lock (B), turning the cam lock clockwise to tighten.



8


B x 8	C x 2	
		
∅15 x 10 mm	∅6 x 30 mm	




Insert the dowel (C) into components 6, connect components 6, 2, 3, and 24 using the cam lock (B), turning the cam lock clockwise to tighten.


9


A x 14



∅6 x 35 mm








Screw eccentric rod(A) into component 7.


10

B x 14




∅15 x 10 mm






Connect components 7, 1, 2, 4, 24, 5, 6, and 7 using the cam lock (B), turning the cam lock clockwise to tighten.





11

A x 7




∅6 x 35 mm






Screw eccentric rod(A) into component 6.





12

A x 4




∅6 x 35 mm








Screw eccentric rod(A) into components 8 and 9.




13




B x 4	C x 6	
		
∅15 x 10 mm	∅6 x 30 mm	



Insert the dowel (C) into component 10, connect components 10, 8, 9, and 11 using the cam lock (B), turning the cam lock clockwise to tighten.




14

A x 2	D x 6	J x 2	
 ∅6 x 35 mm	 ∅3.5 x 12 mm		


Screw eccentric rod(A) into component 13.

Place the hinge (J) on component 13 and secure with screws (D).





15

B x 2





∅15 x 10 mm








Connect components 8, 9, and 13 using the cam lock (B), turning the cam lock clockwise to tighten.
Insert component 12 into the available slots.






16

B x 7	C x 8	
		
∅15 x 10 mm	∅6 x 30 mm	



Insert the dowel (C) into component 6, connect components 6, 8, 11, 9, and 13 using the cam lock (B), turning the cam lock clockwise to tighten.



17


D x 14




∅3.5 x 12 mm


H x 1

Left Right





Place the accessory (H) on components 8 and 9, connecting them to component 14 with screws (D).





18

E x 60




∅4 x 35 mm






x8


Connect components 16, 17, 18, and 19 using screws (E).
Connect components 19, 21, 22, and 23 using screws (E).






x4




19





Insert component 20 into the available slots.





20

A x 60	F x 12	G x 24	
 ∅6 x 35 mm			












Screw eccentric rod(A) into components 25, 26, 27, and 28. Place the handle (F) and secure with screws (G).









21


B x 40




∅15 x 10 mm








x4




x4




Connect components 16, 17, and 19 to components 25 and 26 using the cam lock (B), turning the cam lock clockwise to tighten.


22


B x 20



∅15 x 10 mm










x2


Connect components 19, 21, and 22 to components 27 and 28 using the cam lock (B), turning the cam lock clockwise to tighten.




x2


23

D x 48	DL x 8	DR x 8	
 ∅3.5 x 12 mm			










Place the left slide rail (DL) and right slide rail (DR) on components 16 and 17 and secure with screws (D).




24

D x 24	DL x 4	DR x 4	
 ∅3.5 x 12 mm			






Place the left slide rail (DL) and right slide rail (DR) on components 21 and 22 and secure with screws (D).



25




26





L x 2 L-1	L x 2 L-2	

Secure anti-tip bracket L onto part 7 using screw L as shown.


Place the accessory on component 14, then place component 15.




27

L x 2 L-3	L x 2 L-4				
					


Install anti-tipping device as shown.




1.




2.



3.



4.



WARRANTY

WARRANTY CLAIMS

- There is a 30-day warranty for broken furniture or any other problems that do not work properly. The warranty will start from the date of purchase which must be verified by proof of purchase.

- Before making a claim, we may be able to answer your query, simply call us. Please leave your purchase order number, along with some details of the problem, if you want a replacement part. We will arrange within 48 hours. If there is out of stock, we will reply with a shipping date.

- The product must be used in accordance with the instructions provided. For health reasons.

- For other reasons, if the furniture needs to be returned, it must be cleaned and dried and operated within 30 days of receipt.

Type of Warranty Claim

- Failure to follow the furniture instructions will invalidate the warranty. Attention please.

- Does not include damage during installation, but includes damage during transportation.

Scope of responsibility

- Shall not bear any responsibility for misuse or user damage and / or loss of parts during the installation of furniture.

- After using, the damage and scratches of the furniture are not covered by the warranty.

The Warranty Relates to All Bought in The Us and Covers The Following Areas

- Sheet parts: 1 month from the date of purchase.

- Electrical parts: 1 month from the date of purchase.

RETURNS

CHANGED YOUR MIND AND NEED TO RETURN YOU ITEM?

PLEASE FOLLOW THE BELOW INSTRUCTIONS:

- If you have purchased and have simply changed your mind, follow the retailer's instructions for returns.

DEFECTIVE ITEMS

- If your item is defective in any way, i.e. it doesn't work but you can't identify why, in the first instance, please call us.

DAMAGED ITEMS

- If you receive an order with obvious shipping damage from the retailer, then we suggest the delivery is refused. If the delivery has been accepted and then shipping damage is found, please follow the specific instructions advised by the retailer.
  In all circumstances please save all packaging material and paperwork for the order. Please be aware that if you dispose of packaging material or attempt to return the merchandise without contacting the fulfiller, you jeopardise your chances of making a claim, and you may not receive a credit for the return.

AFTER-SALES CONTACT


adelahu@fufugaga.com


208-820-0068