



INSTRUCTIONS:

1. Remove screws from old plate.
2. Gently pull face plate out (make sure linkage comes out with it).
3. Remove cotter pin from lever.
4. Position new face plate assembly and replace cotter pin.
5. Drop linkage back down in tube.
6. Put screws in and flip lever to open and close.
7. Replace strainer screws and strainer grill.

INSTRUCCIONES:

1. Desaloje los tornillos de la placa usada.
2. Cuidadosamente extraer la placa frontal (asegurarse de que viene el conjunto elevador).
3. Sacar el pasador de la palanca.
4. Colocar la placa nueva y el pasador.
5. Dejar caer el conjunto elevador a través del tubo.
6. Poner los tornillos y mueva la palanca para abrir y cerrar.
7. Reemplace los tornillos y el filtro de rejilla.



R92-05
Polished Nickel
Níquel Pulido