
ASSEMBLY INSTRUCTION

Dining Chair



ASSEMBLY INSTRUCTION

Please read these instructions fully before starting assembly：

1. Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid scratching the parts.

2. Kindly follow the assembly instructions step by step.

3. Do not tighten all screws and bolts until the table is fully assembled.


4. Unscrew the protective plastique supports from the metal insert of the table legs before assembly.

5. Parts of the assembly will be easier with 2 people.

Care and maintenance：

Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.


ASSEMBLY INSTRUCTION



ASSEMBLY INSTRUCTION


Part List

Ⓐ




BACK FRAME (2 pcs)

Ⓑ



SEAT FRAME (2 pcs)





Ⓒ



LEG (4 pcs)


ASSEMBLY INSTRUCTION

Hardware List

①  Ø 1/4" x 40 mm	②  Ø 1/4" x 55 mm
BOLT (4 pcs)	BOLT (8 pcs)
③  Ø 1/4" x 75 mm	④  Ø5/16" x 13 mm
BOLT (8 pcs)	LOCK WASHER (20 pcs)
⑤  Ø5/16" x 19 X 2 mm	⑥  4 mm
FLAT WASHER (20 pcs)	ALLEN KEY (1 pc)


ASSEMBLY INSTRUCTION

STEP 1:



BOLT Ø 1/4" x 40 mm	BOLT Ø 1/4" x 75 mm	LOCK WASHER Ø5/16" x 13 mm	FLAT WASHER Ø5/16" x 19 X 2 mm	ALLEN KEY 4 mm x 75mm
①x 4	③x 8	④x12	⑤x 12	⑥x 1

STEP 2:



BOLT Ø 1/4" x 55 mm	LOCK WASHER Ø5/16" x 13 mm	FLAT WASHER Ø5/16" x 19 X 2 mm	ALLEN KEY 4 mm x 75mm
②x 8	④x 8	⑤x 8	⑥x 1

ASSEMBLY INSTRUCTION

COMPLETE

