
Cabinet

Assembly Instruction – Please keep properly for future reference.

If you find any missing boxes, damaged parts, or accessory shortages, please contact the customer service team of your purchasing channel immediately. We will resolve the issue as quickly as possible.



THE FOLLOWING INFORMATION:

- Order number
- Purchase platform
- Purchase date
- Detailed description of the issue along with photos (if applicable)

Important – Please read these instructions carefully before starting the installation.

EN

EN

Before Assembly

Thank you for choosing our product!
To ensure a smooth installation process, please read this guide carefully to familiarize yourself with the required tools, materials, and installation steps.
Follow the relevant sections to avoid any damage caused by improper installation, and make sure to review all operation and safety guidelines for correct installation procedures.

Packaging Notice:

If you find any missing boxes, damaged parts, or accessory shortages, please contact the customer service team of your purchasing channel immediately. We will resolve the issue as quickly as possible.

Safety and Care Advice

Important :
Please read these instructions fully before starting assembly.

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.
- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



- To reduce the likelihood of damaging your product please ensure that your power drill is set on a low torque setting.

Care and Maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal center.

Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts.
- Regularly check and ensure that all bolts and fittings are tightened properly.

Warning

In order to help prevent overturning, please follow these instructions.

- Use the anti tip strap or wall fixing method provided (if applicable).
- Do not allow children to climb or hang on the furniture.
- Do not open more than one drawer at a time.
- Do not place heavy items in the top drawers.
- Do not place heavy items on top of the furniture, unless the furniture has been designed for this purpose.
- Please note that only the anti tip strap is provided. You will need to provide wall plugs and screws applicable for your wall type.

EN

Customer Service Guide

Thank you for choosing our product! We are committed to providing you with excellent service. If you find any missing parts, damaged packaging, or product damage after receiving all packages, please follow the steps below to quickly contact our customer service team. We will do our best to resolve your issue.

1. Missing Parts

Verify Parts:

1. Refer to the “Parts List” in the manual to verify the name, specifications, and quantity of the missing parts.
2. Take a clear photo of the parts list and mark the missing parts with detailed information, e.g., “Missing 5 pieces of M6×30mm screws.”

Contact Us:

By Email:

Sendanemailwiththesubjectline"MissingPartsIssue."Includethefollowinginthe email:

- A description of the missing parts and a photo of the parts list.
- Order details (order number, purchase platform, purchase date).

2. Product or Packaging Damage

If it affects normal use:

Steps:

1. Take clear photos or videos showing the damaged parts and the extent of the damage (multi-angle shots are recommended).
2. Email the photos/videos along with order details, with the subject line “Product Damage Issue.”

Resolution:

After verification, we will arrange for a replacement part, product exchange, or refund as quickly as possible.

Resolution:
After verification, we will arrange for a replacement part, product exchange, or refund as quickly as possible.

If it does not affect normal use:

Steps:
1. Contact our customer service team.
2. Provide a description of the damage and include relevant photos or videos.

Resolution:
We will provide repair guidance or an appropriate compensation plan based on the specific situation.

Helpful Tips

To process your issue efficiently, please prepare the following information:


- Order details (order number, purchase platform, purchase date).
- Clear photos or videos.
- We are committed to providing quick and professional solutions, no matter the size of the issue, to ensure your satisfaction.

Thank you for your trust and support!
We hope you enjoy using our product!


EN

Parts List - Panels


Please check you have all the panels listed below.




1 749*70*45mm x1




2 749*395*12mm x1




3 230*40*32mm x6




4 749*70*45mm x1




5 749*395*12mm x1




6 749*465*12mm x1




7 749*465*12mm x1




8 563*50*12mm x2




10 1164*110*12mm x1




11 1164*110*12mm x1




12 256*183*15mm x2




13 256*50*12mm x4




14 1192*467*12mm x1




15 1092*75*12mm x2




16 378*75*12mm x2




17 562*395*12mm x1




18 534*277*15mm x1




19 534*277*15mm x1




20 330*140*12mm x6




21 330*140*12mm x6




22 218*140*12mm x6



23 325*226*2.7mm x6



24 250*175*15mm x6




25 563*183*15mm x1

EN


Parts List - Fittings

Please check you have all the fittings listed below.


Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied are required.




A Ø7x37mm x60




B Ø15x9.6mm x68




C Ø6x30mm x56




D Ø3.5x12mm x62




E Ø5x40mm x65



F Ø6x50mm x8




G Drawer Slide x12




H Ø7x68mm x8




I Protective Foot x4




J Door Stopper x1




K Handle & Fixings x8




L Hinge x4




M Shelf Support Pin x4



N 4*12mm Screw x12




O Wall Fixing Pack x3



P Sink x1


Tools required



Phillips screwdriver
(medium & large)

Ruler

Use this ruler to help correctly identify the screws




The screws length is measured from the head to the point (30mm screw shown).

Using Camlocks

Step 1


Connect the male camlock as directed in the assembly instructions using a screwdriver.

DO NOT OVER TIGHTEN.



Step 2


Push the male camlock into the entry hole.



Step 3

Insert the female camlock as shown in the instructions.

Note: ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.




Step 4

Turn the female camlock clockwise with a screwdriver.


You should feel a click when the camlock is locked in place.


The joint is now secure.



Assembly Instructions

EN







EN

Step 1

D	G
Ø3.5x12mm x18	Drawer Slide x6




⚠ Note: Please pay attention to the direction of the drawer slides.




Attach drawer slide (G) to part (6, 7) using screw (D) and a screwdriver.

Step 2




Insert wooden dowel (C) into part (6, 7).

Step 3




Insert wooden dowel (F) into part (8, 25).

Step 4




Insert wooden dowel (C) into part (25).
Attach part (8) to part (25) using screw (E) with a screwdriver.

Step 5




Attach part (6, 7) to part (8, 25) using screw (H) and a screwdriver.

Step 6




Insert wooden dowel (C) into part (10, 11).

Step 7




Attach part (10, 11) to part (6, 7) using screw (E) and a screwdriver.

Step 8




Attach part (12, 13) to part (7), then insert and secure cam lock (B) to part (12, 13) to lock it.

Step 9




Insert wooden dowel (C) into part (12, 13).

Step 10



Attach cam bolt (A) to part (4, 5) with a screwdriver.
Insert wooden dowel (C) into part (5).


Step 11



Attach part (4) to part (5), then insert and secure cam lock (B) to part (5) to lock it.

Step 12


C
Ø6x30mm x6



Insert wooden dowel (C) into part (3).

Step 13


E
Ø5x40mm x9




Attach part (3) to part (5) using screw (E) and a screwdriver.

Step 14

D	G
Ø3.5x12mm x9	Drawer Slide x3



⚠ Note: Please pay attention to the direction of the drawer slides.




Attach drawer slide (G) to part (3, 4) using screw (D) and a screwdriver.


Step 15

B



Ø15x9.6mm x8







Attach part (4, 5) to part (10, 11, 12, 13), then insert and secure cam lock (B) to part (10, 11, 12, 13) to lock it.

Step 16

B

Ø15x9.6mm x4






Attach part (12, 13) to part (6), then insert and secure cam lock (B) to part (12, 13) to lock it.

Step 17


C

Ø6x30mm x4




Insert wooden dowel (C) into part (12, 13)

Step 18



Attach cam bolt (A) to part (1, 2) with a screwdriver.
Insert wooden dowel (C) into part (2).

Step 19




Attach part (1) to part (2), then insert and secure cam lock (B) to part (2) to lock it.

Step 20

C

Ø6x30mm x6




Insert wooden dowel (C) into part (3).

Step 21

E


Ø5x40mm x9




Attach part (3) to part (2) using screw (E) and a screwdriver.

Step 22

D	G
Ø3.5x12mm x9	Drawer Slide x3



⚠ Note: Please pay attention to the direction of the drawer slides.




Attach drawer slide (G) to part (1, 3) using screw (D) and a screwdriver.


Step 23

B



Ø15x9.6mm x8






Attach part (1, 2) to part (10, 11, 12, 13), then insert and secure cam lock (B) to part (10, 11, 12, 13) to lock it.

Step 24

E

Ø5x40mm x11



Attach part (14) to part (2, 5, 6, 7) using screw (E) and a screwdriver.


EN

Step 25

A




Ø7x37mm x10



CAM-LOCK

Tighten until shoulder is flush with panel.Do not overtighten or undertighten(see example below)




Attach cam bolt (A) to part (14) with a screwdriver.

Step 26

A Ø7x37mm x4


C Ø6x30mm x12



Attach cam bolt (A) to part (15) with a screwdriver.
Insert wooden dowel (C) into part (15, 16).

Step 27

B Ø15x9.6mm x4




Attach part (15) to part (16), then insert and secure cam lock (B) to part (16) to lock it.


Step 28

B



Ø15x9.6mm x10






Attach part (15, 16) to part (14), then insert and secure cam lock (B) to part (15, 16) to lock it.

Step 29

I Protective Foot x4




Insert protective foot (I) to part (15).

Step 30

D Ø3.5x12mm x2


J Door Stopper x1



Attach door stopper to part (14) using screw (D) with a screwdriver.


EN

Step 31



Insert shelf support pins (M) into part (6, 7), and then place part (17) on the top of support pins.


Step 32



Attach hinge (L) to part (18, 19) using screw (D) with a screwdriver.


Step 33


D  Ø3.5x12mm x8	K  Handle & Fixings x2



Attach hinge (L) to part (6, 7) using screw (D) with a screwdriver.
Attach handle (K) to part (18,19) using screw (K) with a screwdriver.


Step 34






To adjust the vertical height.

Loosen the two screws "A" on both hinges.They are usually in slotted holes which allows you to adjust up or down by a few mm.Then tighten back up.



To adjust depth.

Loosen screw "B" and adjust door, if the door cannot be adjusted, please loosen screw "C", then try again. Tighten screw "B" and "C".




To adjust side ways.

Turning the screw "C" on BOTH hinges on each door.

Step 35

D	x8
Ø3.5x12mm	



Secure hinge (L) to part (6, 7) using screw (D) with a screwdriver.


EN

Step 36

E



Ø5x40mm x24




Attach parts (20, 21) to part (22) using screw (E) and a screwdriver.
Slide part (23) into the grooves.

Step 37

A



Ø7x37mm x24




Attach cam bolt (A) to part (24) with a screwdriver.

Step 38

B



Ø15x9.6mm x24




Attach part (24) to part (20,21), then insert and secure cam lock (B) to part (20, 21) to lock it.

Step 39

K




Handle & Fixings x6




Attach handle (K) to part (24) using screw (K) with a screwdriver.

Step 40



Slide the drawer slide (G) into the grooves on both sides of the drawer as shown in the diagram.

Step 41




Use screw (N) to secure drawer slide (G) to the drawer.


Step 42


O



Wall Fixing Pack x3









EN

Step 43



Sink x1



Apply a thin layer of silicone sealant around the top of the vanity, then carefully set the sink (P) in place.
Wipe off any excess silicone with a damp rag.