

HamiltonBeach®

PROFESSIONAL

Read before use/Lire avant utilisation/Lea antes de usar.

For questions:
1-800-851-8900
Recipes, tips, product
information, and
registration:
hamiltonbeach.com

Pour des questions :
1-800-267-2826
Recettes, des conseils,
des renseignements sur le
produit et l'enregistrement :
hamiltonbeach.ca

Para preguntas:
1-800-851-8900
Recetas, consejos,
información del producto
y registro:
hamiltonbeach.com.mx

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

1. Read all instructions.

2. This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they are closely supervised and instructed concerning use of the appliance by a person responsible for their safety.

3. Close supervision is necessary when any appliance is used by or near children. Children should be supervised to ensure that they do not play with the appliance.

4. Do not touch hot surfaces or hot water. Use handles or knobs. Care must be taken since burns can occur from touching hot parts or from spilled hot liquid.

5. To protect against fire, electric shock, and personal injury, do not immerse cord, plug, power base, or electric kettle in water or other liquid.

6. Unplug from outlet when kettle is not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.

7. Do not operate any appliance with a damaged supply cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner. Supply cord replacement and repairs must be conducted by the manufacturer, its service agent, or similarly qualified persons in order to avoid a hazard. Contact Customer Service for information on examination, repair, or adjustment as set forth in the Limited Warranty.

8. The use of attachments not recommended or sold by the appliance manufacturer may cause fire, electric shock, or personal injury.

9. Do not use outdoors.

10. Do not let cord hang over edge of table or counter, or touch hot surfaces, including the stove.

11. Do not place electric kettle on or near a hot gas or electric burner or in a heated oven.

12. To disconnect electric kettle, press Power ON/OFF Button for three seconds and then remove plug from wall outlet. To unplug, grasp the plug and pull from the outlet. Never pull from the power cord.

13. Do not use appliance for other than intended use.

14. Do not use for other than heating water. Other liquids or food will contaminate the interior and void warranty.

15. Do not allow kettle to boil dry.

16. To avoid circuit overload, do not operate another high-wattage appliance on the same circuit.

17. **WARNING:** If the kettle is overfilled, boiling water may be ejected.

18. **WARNING:** Scalding may occur from escaping steam; keep away from lid vent opening. Do not open lid during the heat cycle or when pouring hot water.

19. Be certain kettle lid is securely in place during operation and when pouring hot water. Do not use force when placing lid on kettle.

20. The kettle outer surface is subject to residual heat after use. Allow to cool before touching.

21. Use only the power base provided.

22. **WARNING: Fire and Shock Hazard.** Do not immerse or spill liquid on power base.

23. Do not clean kettle with cleansers, steel wool pads, or other abrasive material.

SAVE THESE INSTRUCTIONS

Other Consumer Safety Information

This appliance is intended for household use only.

⚠ WARNING Electrical Shock Hazard: This appliance is provided with either a polarized (one wide blade) or grounded (3-prong) plug to reduce the risk of electric shock. The plug fits only one way into a polarized or grounded outlet. Do not defeat the safety purpose of the plug by modifying the plug in any way or by using an adapter. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, have an electrician replace the outlet.

The length of the cord used on this appliance was selected to reduce the hazards of becoming tangled in or tripping over a longer cord. If a longer cord is necessary, an approved extension cord may be used. The electrical rating of the extension cord must be equal to or greater than the rating of the appliance. If the appliance is of the grounding type, the extension cord should be a grounding-type, 3-wire cord. Care must be taken to arrange the extension cord so that it will not drape over the countertop or tabletop where it can be pulled on by children or accidentally tripped over.

To avoid an electrical circuit overload, do not use another high-wattage appliance on the same circuit with this appliance.

If using an extension cord, it should be connected to the unit's power cord before it is plugged into the outlet. In the case of a power failure, the same procedure should be followed.

Parts and Features

1. Lid

2. Anti-Scale Mesh Filter (inside spout)

3. Infuser

4. Light Ring

5. Lid Knob

6. Temperature Display

7. ⏻ (Power ON/OFF) Button

8. Temperature Selection Button (on handle)

9. Power Base with Cord Storage

How to Use

⚠ CAUTION Burn Hazard. Do not overfill kettle. Boiling water may spit out of the spout.

Before first use: Pull up on Lid Knob to remove Lid and fill Kettle with water to MAX fill line. Replace Lid and push down to secure it in place. Plug into outlet. Press Temperature Selection Button to select 212°F, then press ⏻ (Power ON/OFF) Button to turn Kettle ON. Kettle will bring water to a boil, then shut off automatically. Discard water and repeat 2–3 times, rinsing out Kettle each time. Ensure Mesh Filter is in place. Kettle is now ready for use.

- Plug into outlet. Light Ring illuminates white.
- Pull up on Lid Knob to remove Lid. Fill Kettle with desired amount of water. Ensure that water level is between 0.25 L/1 cup and MAX fill line.
- Replace Lid and push down to secure it in place. Make sure Power Base is on a level surface.
- Press Temperature Selection Button to select desired temperature. Press ⏻ (Power ON/OFF) Button. Light Ring illuminates red while water is heating.
- Kettle switches to keep warm for 1 hour after desired temperature is reached. Water that was boiled at 212°F (100°C) will only keep warm to 200°F (93°C). Light Ring illuminates amber while in keep warm mode. After 1 hour, Kettle will enter sleep mode.
- Press and hold ⏻ (Power ON/OFF) for 3 seconds to put Kettle into sleep mode. Unplug when not in use.

Change from Fahrenheit to Celsius

Press and hold Temperature Selection Button for 3 seconds to switch between F to C.

Intelligent Keep Warm

When Kettle transitions to keep warm, removing it from Power Base and replacing it within 1 minute allows continuation in keep warm mode. To exit keep warm mode, press ⏻ (Power ON/OFF) Button.

Sleep Mode

After about 2 minutes of inactivity when power is on, or at end of keep warm, Kettle enters sleep mode. To wake it up, remove Kettle from Power Base or press any button.

Anti-Scale Mesh Filter

Scale is caused by lime and calcium in hard water. Mesh Filter will prevent these suspended particles from being poured out of Kettle. Filter should be cleaned periodically to ensure optimum performance. Always operate Kettle with Mesh Filter in place.

How to Brew Tea

1. Remove Lid with Infuser attached by holding handle with one hand and pulling straight up on Lid Knob with other hand.

2. Remove Infuser from Lid by placing hand at top of Infuser close to the Lid and gently twist and pull forward.

3. Measure 1 rounded teaspoon of loose tea per 6 to 8 oz. (177 to 237 mL) of water and place in Infuser.

4. Replace Infuser in Lid by sliding back into grooves and turning slightly.

5. Add desired amount of water to Kettle, using 6 to 8 oz. (177 to 237 mL) water per cup, and press Temperature Selection Button for chosen tea.

6. If using tea bags, add to cup and pour heated water directly over tea bag.

7. Steep tea for suggested time shown in chart below. For stronger tea, add more leaves rather than infusing longer than recommended. Tea that is over-steeped can become bitter.

Temperature & Tea Guide

TYPE	TEMP. °F	STEEP TIME
Black/Boil	212° (100° C)	5 minutes
Herbal Tea	200° (93° C)	5 minutes
Oolong Tea	190° (88° C)	3-5 minutes
White Tea	180° (82° C)	3-4 minutes
Green Tea	170° (77° C)	3-5 minutes
Delicate Tea	160° (71° C)	2 minutes
Yerba Mate	150° (65° C)	3-5 minutes
Matcha	140° (60° C)	
Hot Chocolate	130° (54° C)	3-5 minutes
Hot Water	120° (49° C)	

NOTE: These temperature settings can vary depending on a number of factors, such as altitude, impurities in water, and amount of water in Kettle.

Care and Cleaning

⚠ WARNING Electrical Shock Hazard. Do not immerse kettle, power base, or plug in water or any other liquid. DO NOT PLACE IN A DISHWASHER FOR CLEANING.

- Unplug Kettle. Empty any remaining water and rinse inside. Allow Kettle to cool.
- To avoid scale/lime deposit buildup, empty Kettle after each use. To remove discoloration or scale/lime deposit from heating element: Place 1/2 teaspoon (2.5 mL) cream of tartar (available in spice aisle of grocery store) into Kettle. Then fill Kettle 1/2 full with water. Plug into outlet, press ⏻ (Power ON/OFF) Button, and bring to boil. Press ⏻ (Power ON/OFF) Button. Unplug and let cool. Rinse several times with clean tap water.
- To clean Infuser, remove from Lid. Empty tea leaves into compost or trash can. Rinse after each use with warm water to prevent tea residue from drying and hardening. If necessary, use a soft brush to gently scrub any dried tea.
- Wipe exterior of Kettle with a damp cloth. Do not use abrasive scouring pads or powders since they may scratch smooth surface of Kettle.

Troubleshooting

Kettle boils dry.

Kettle's heating element is protected by two automatic safety devices. If Kettle is accidentally switched on without being filled with water, or is allowed to boil dry, it will automatically switch off. If this happens:

- Refill Kettle with cool water and wait for about 30 seconds. LED screen should turn back on. Check that Kettle functions correctly.
- Unplug Kettle and wait about 20 minutes for element to cool down.

Kettle does not work.

- Ensure cord is plugged into a working outlet and Kettle is seated on Power Base.
- Ensure ⏻ (Power ON/OFF) Button has been pressed.
- If Kettle heats but does not boil, it may need descaling (see "Care and Cleaning" section).
- If Kettle has been accidentally turned on without being filled with water or allowed to boil dry, see Kettle Boils Dry above.

Kettle floor discolors.

- Kettle may need descaling (see "Care and Cleaning" section).
- Some discoloration of stainless steel heating elements is normal. This does not affect performance of Kettle.

Error code appears on Display.

- E03: High Altitude Detection. Set desired temperature to a lower setting, as Kettle is unable to reach set temperature due to altitude.
- For all other error codes, contact Customer Service.

Mesh Filter not in place.

- To replace Filter, slide Filter tabs up into grooves and push lower tab until it snaps into place.

Hamilton Beach in no way guarantees the availability of replacement parts, repair services and information necessary to repair our products. For information on what parts and repair services may currently be available, please contact us using the methods provided in this manual.

Limited Warranty

This warranty applies to products purchased and used in the U.S. and Canada. This is the only express warranty for this product and is in lieu of any other warranty or condition.

This product is warranted to be free from defects in material and workmanship for a period of three (3) years from the date of original delivery in the U.S. and Canada. During this period, your exclusive remedy is replacement of this product, or any component found to be defective, at our option; however, you are responsible for all costs associated with returning the product to us and our returning a product or component under this warranty to you. If the product or component is unavailable, we will replace with a similar one of equal or greater value.

This warranty does not cover glass, filters, wear from normal use, use not in conformity with the printed directions, or damage to the product resulting from accident, alteration, abuse, or misuse. This warranty extends only to the original consumer purchaser or gift recipient. Keep the original sales receipt, as proof of purchase is required to make a warranty claim. This warranty is void if the product is used for other than single-family household use or subjected to any voltage and waveform other than as specified on the rating label (e.g., 120 V ~ 60 Hz).

We exclude all claims for special, incidental, and consequential damages caused by breach of express or implied warranty. All liability is limited to the amount of the purchase price. **Every implied warranty, including any statutory warranty or condition of merchantability or fitness for a particular purpose, is disclaimed except to the extent prohibited by law, in which case such warranty or condition is limited to the duration of this written warranty.** This warranty gives you specific legal rights. You may have other legal rights that vary depending on where you live. Some states or provinces do not allow limitations on implied warranties or special, incidental, or consequential damages, so the foregoing limitations may not apply to you.

To make warranty claim, do not return this appliance product to the store; retain the product in your possession. Please call 1.800.851.8900 in the U.S. or 1.800.267.2826 in Canada or write Hamilton Beach Brands, Inc., Attn: Consumer Affairs, 261 Yarkin Road, Southern Pines, NC 28387, or visit hamiltonbeach.com/customer-service in the U.S. or hamiltonbeach.ca/customer-service in Canada. For faster service, include the model, type, and series numbers on your appliance.

PRÉCAUTIONS IMPORTANTES

Pour utiliser un appareil électroménager, vous devez toujours prendre des mesures élémentaires de sécurité pour réduire le risque d'incendie, de choc électrique et/ou de blessure corporelle, en particulier les mesures suivantes :

- Lire toutes les instructions.
- Cet appareil n'est pas destiné à être utilisé par des personnes (y compris les enfants) dont les capacités physiques, sensorielles ou mentales sont réduites, ou manquant d'expérience et de connaissance, sauf si elles sont étroitement surveillées et instruites sur l'utilisation de l'appareil par une personne responsable de leur sécurité.
- Une surveillance étroite est requise pour tout appareil utilisé par ou près des enfants. Surveiller que les enfants ne jouent pas avec l'appareil.
- Ne pas toucher les surfaces chaudes ou l'eau bouillante/chaude. Utiliser les poignées ou les boutons. Prendre toutes les précautions nécessaires pour éviter les brûlures causées par les surfaces chaudes ou les déversements de liquide chaud.
- Pour éviter le risque d'incendie, de choc électrique, et les blessures, ne pas immerger le cordon d'alimentation, la fiche, la base d'alimentation, ni la bouilloire électrique dans l'eau ou un autre liquide.
- Débrancher de la prise murale dès la fin de l'utilisation et avant le nettoyage. Laisser refroidir l'appareil avant d'installer ou de retirer des pièces et avant de le nettoyer.
- Ne pas faire fonctionner un appareil électroménager avec un cordon ou une fiche endommagée, ou lorsque l'appareil ne fonctionne pas bien ou a été échappé ou endommagé d'une manière quelconque. Le remplacement et la réparation du cordon d'alimentation doivent être faits par le fabricant, son agent de service ou toute personne qualifiée de façon à éviter tout danger. Veuillez communiquer avec le service à la clientèle pour obtenir de l'information concernant l'inspection, la réparation ou le réglage, comme précisé dans la garantie limitée.
- L'utilisation d'accessoires non recommandés ou vendus par le fabricant de l'appareil peut provoquer un incendie, un choc électrique ou blesser quelqu'un.
- Ne pas utiliser à l'extérieur.
- Ne pas laisser pendre le cordon de la table ou du comptoir et éviter tout contact entre le cordon et les surfaces chaudes, incluant la cuisinière.
- Ne pas placer la bouilloire électrique sur ou près d'un brûleur chaud à gaz ou électrique ou dans un four chaud.
- Pour débrancher la bouilloire électrique, appuyer sur le bouton ⏻ (marche/arrêt), puis débrancher la fiche de la prise murale. Pour le débrancher, tenir la fiche et la retirer de la prise. Ne jamais tirer sur le cordon.
- N'utiliser cet appareil que pour les fonctions auxquelles il est destiné.
- Cet appareil n'est destiné qu'à faire bouillir l'eau. Bouillir d'autres types de liquide ou d'aliments contaminera l'intérieur de l'appareil et annulera la garantie.
- Ne pas faire fonctionner la bouilloire sans liquide.
- Pour éviter la surchauffe d'un circuit électrique, ne pas brancher d'autre appareil de haute puissance sur le même circuit.
- AVERTISSEMENT :** Si la bouilloire est trop pleine, l'eau bouillante peut éclabousser.
- AVERTISSEMENT :** Des brûlures causées par la vapeur qui s'échappe peuvent survenir; garder l'ouverture de l'évent du couvercle loin de vous. Ne pas ouvrir le couvercle pendant le cycle de chauffage ou en versant de l'eau chaude.
- S'assurer que le couvercle de la bouilloire est bien fixé pendant l'utilisation et au moment de verser l'eau chaude. Ne pas utiliser la force pour fixer le couvercle de la bouilloire.

- La surface externe de la bouilloire peut rester chaude après l'utilisation. Laisser la surface refroidir avant d'y toucher.
- N'utiliser que la base d'alimentation fournie.
- AVERTISSEMENT : Risque d'incendie et de choc électrique.** Ne pas immerger la base dans un liquide ou renverser du liquide sur la base.
- Ne pas nettoyer la bouilloire avec des nettoyeurs, des tampons d'acier ou autres matériaux abrasifs.

CONSERVER CES INSTRUCTIONS

Autres consignes de sécurité pour le consommateur

Cet appareil est destiné à un usage domestique uniquement.

⚠ AVERTISSEMENT Risque de choc électrique : Cet appareil est doté d'une fiche polarisée (lame plus large) ou d'une fiche (3 lames et mise à la terre) pour réduire le risque d'électrocution. Cette fiche s'insère d'une seule manière dans une prise polarisée ou prise avec mise à la terre. Ne pas transformer le dispositif de sécurité de la fiche en modifiant celle-ci de quelconque façon ou en utilisant un adaptateur. Si vous ne pouvez pas insérer complètement la fiche dans la prise, inversez la fiche. Si elle refuse toujours de s'insérer, faire remplacer la prise par un électricien.

La longueur du cordon installé sur cet appareil a été sélectionnée afin de réduire les risques d'enchevêtrement ou de faux pas causés par un fil trop long. L'utilisation d'une rallonge approuvée est permise si le cordon est trop court. Les caractéristiques électriques de la rallonge doivent être équivalentes ou supérieures aux caractéristiques de l'appareil. Prendre toutes les précautions nécessaires pour installer la rallonge de manière à ne pas la faire courir sur le comptoir ou sur une table pour éviter qu'un enfant ne tire sur le cordon ou trébuche accidentellement.

Pour éviter la surcharge du circuit électrique, ne pas utiliser un autre appareil à haute puissance sur le même circuit que cet appareil.

Avec l'utilisation d'une rallonge, celle-ci doit être branchée au cordon d'alimentation de l'appareil avant de la brancher dans la prise murale. En cas de panne de courant, la même méthode doit être suivie.

Pièces et caractéristiques

1. Couvercle

2. Filtre métallique antitartre (intérieur du bec verseur)

3. Infuseur

4. Anneau lumineux

5. Poignée du couvercle

6. Affichage de la température

7. Bouton ⏻ (marche/arrêt)

8. Bouton de sélection de la température (sur la poignée)

9. Base d'alimentation avec enrouleur de cordon

Pour commander des pièces, visiter :
hamiltonbeach.ca/parts

Utilisation

⚠ ATTENTION Risque de brûlures. Ne pas trop remplir la bouilloire. L'eau brûlante peut jaillir hors du bec.

Avant la première utilisation : Tirer sur la poignée du couvercle pour retirer le couvercle et remplir la bouilloire avec de l'eau jusqu'à la ligne de remplissage MAX. Remplacer le couvercle et le pousser vers le bas pour bien l'enfoncer. Brancher l'appareil dans une prise. Appuyer sur le bouton de sélection de la température pour choisir 100 °C (212 °F), puis sur le bouton ⏻ (marche/arrêt) pour mettre en marche la bouilloire. La bouilloire porte l'eau à ébullition, puis s'éteint automatiquement. Jeter l'eau et répéter l'opération deux ou trois fois en rinçant la bouilloire chaque fois. Veiller à ce que le filtre métallique soit en place. La bouilloire est maintenant prête à être utilisée.

- Brancher l'appareil dans une prise. L'anneau lumineux s'allume en blanc.
- Tirer sur la poignée du couvercle pour retirer le couvercle. Remplir la bouilloire avec la quantité d'eau souhaitée. Veiller à ce que le niveau d'eau se trouve entre 0,25 l/1 tasse et la ligne de remplissage MAX.
- Remplacer le couvercle et le pousser vers le bas pour bien l'enfoncer. S'assurer que la base se trouve sur une surface à niveau.
- Appuyer sur le bouton de sélection de la température pour choisir la température souhaitée. Appuyer sur le bouton ⏻ (marche/arrêt). L'anneau lumineux s'allume en rouge durant le chauffage de l'eau.
- La bouilloire passe en mode de garde au chaud une fois la température souhaitée atteinte et y reste pour une heure. L'eau qui a bouilli à une température de 100 °C (212 °F) ne reste au chaud qu'à une température de 93 °C (200 °F). L'anneau lumineux s'allume en ambre en mode de garde au chaud. Après une heure, la bouilloire passe en mode veille.
- Appuyer sur le bouton ⏻ (marche/arrêt) et le garder enfoncé trois secondes pour faire passer la bouilloire en mode veille. Débrancher l'appareil lorsqu'il n'est pas utilisé.

Changement des degrés Fahrenheit aux degrés Celsius

Appuyer sur le bouton de sélection de la température et le garder enfoncé trois secondes pour passer des degrés F aux degrés C.

Mode de garde au chaud intelligent

Une fois que la bouilloire passe en mode de garde au chaud, elle le reste même si la bouilloire est retirée puis replacée sur la base dans un délai de moins d'une minute. Pour sortir du mode de garde au chaud, appuyer sur le bouton ⏻ (marche/arrêt).

Mode veille

La bouilloire entre en mode veille à la fin du cycle de garde au chaud ou après environ 2 minutes d'inactivité lorsqu'elle est en marche. Pour réactiver la bouilloire, la retirer de la base ou appuyer sur n'importe quel bouton.

Filtre métallique antitartre

Le tartre est causé par la chaux et le calcium contenu dans l'eau calcaire. Le filtre métallique retient ces particules en suspension dans la bouilloire. Le filtre doit être nettoyé périodiquement pour assurer sa qualité de filtration optimale. Toujours faire fonctionner la bouilloire avec le filtre en maille en place.

Infusion du thé

- Retirer l'infuseur du couvercle en plaçant la main sur le dessus du diffuseur, près du couvercle et en tournant légèrement avant de le tirer vers vous.
- Mesurer une cuillère à thé bien garnie de thé en feuille pour chaque 177 à 237 mL (6 à 8 oz) d'eau et déposer le thé dans l'infuseur.

