Santa & Dinosaur Inflatable



Illustrated assembly guide

MODEL XD8178

Finished dimensions
52.75 in L x 33.85 in W x 96.45 in H

Keep the power disconnected while joining the frame and light connections. Use the supplied power source for your item.

Before you begin

Arrange the components on a clean surface. Inflatable decoration, power adaptor, tether ropes and ground stakes.



Have scissors ready when zip ties are used. Cut only excess tie ends; keep scissors clear of the light wires.

Assembly sequence

Follow the numbered steps. Check each frame and cord connection before applying power.

1 Prepare a clear area



Lay the inflatable flat on a clear surface. Locate the power adaptor, tether ropes and ground stakes.

2 Inflate the decoration



Connect the supplied power adaptor to inflate the decoration. Allow it to rise fully before securing the tether ropes.

3 Attach the tether ropes



Attach the ropes to the side loops shown in the video. Anchor the ropes using the included ground stakes.

4 Adjust and check stability



Adjust rope tension for stability. Check that the inflatable is fully raised and securely anchored, then verify the lights and display.

Warranty?
Troubleshooting?

Scan the QR code for instructions, support, & registration.

XProductSupport.com/product/XD8178

Instructions, support & warranty

Scan the mini card or click below to:

Watch the instructional video
Create a support ticket
Register your item for warranty

XProductSupport.com/product/XD8178