



ASSEMBLY INSTRUCTIONS

1. Insert tube (A) into tube (B) then tighten screw (D) with wrench (C-included).
2. Clockwise screw tube (F) into lamp base (E).
3. Clockwise screw tube (G) into tube (F)
4. Clockwise screw tube (H) into tube (G)
5. Clockwise screw tube (I) into tube (H).
6. Gently pull cord through the tubes.
7. Remove pre-assembled screw (J) from the tube (I)
8. Insert whole part (N) into tube (I) then clockwise tighten screw (J).
9. Remove pre-assembled socket ring (M) from the socket (K).
10. Put the fabric shade (L) onto the socket (K) then tighten socket ring (M).

CLEANING

DO NOT USE POLISH OR CLEANERS ON YOUR LAMP, JUST WIPE CLEAN WITH SOFT CLOTH.

WARNING

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER). AS A FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK, THIS PLUG WILL FIT IN A POLARIZED OUTLET ONE WAY ONLY. IF IT DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS THE PLUG CAN BE FULLY INSERTED.

DIRECTIVES D'ASSEMBLAGE

1. Insérez le tube (A) dans le tube (B), utilisez la clé (C, fournie) pour serrer les vis (D).
2. Vissez délicatement le tube (F) dans la base (E).
3. Vissez délicatement le tube (G) sur le tube (F).
4. Vissez délicatement le tube (H) sur le tube (G).
5. Vissez délicatement le tube (I) sur le tube (H).
6. Passe doucement le fil dans le tube.
7. Débrancher une vis (J) de préassemblage d'un tube (I)
8. L'ensemble de la pièce (N) est inséré dans le tube (I) et la vis (J) de tige est insérée dans l'aiguille..
9. Retirez l'anneau de manchon (M) du support de la lampe (K).
10. Placez l'abat-jour (L) dans le support de lampe (K) et l'anneau de manchon (M) dans le support de lampe (K)

NETTOYAGE

NE PAS UTILISER DE VERNIS OU DE DÉTERTERGENT SUR VOTRE LAMPE. ESSUYER SEULEMENT AVEC UN CHIFFON DOUX ET PROPRE.

AVERTISSEMENT

CETTE LAMPE PORTATIVE EST MUNIE D'UNE FICHE POLARISÉE (UNE DES LAMES EST PLUS LARGE QUE L'AUTRE). AFIN DE RÉDUIRE LES RISQUES DE DÉCHARGE ÉLECTRIQUE, IL N'Y A QU'UNE SEULE FAÇON D'INSÉRER CETTE FICHE DANS UNE PRISE DE COURANT POLARISÉE. SI LA FICHE NE S'INSÈRE PAS CORRECTEMENT DANS LA PRISE, LA RETOURNER DE CÔTÉ. SI LA FICHE N'ENTRE TOUJOURS PAS, COMMUNIQUER AVEC UN ÉLECTRICIEN QUALIFIÉ. NE PAS UTILISER AVEC UNE RALLONGE À MOINS QUE LA FICHE PUISSE Y ÊTRE INSÉRÉE COMPLÈTEMENT.