

TV Stand

Assembly Instructions - Please keep for future reference


⚠ NOTE:

Comes with TWO PACKAGES with TWO TRACKINGS,may NOT be delivered at the same time.





Carton 1 of 2



Carton 2 of 2

Dimensions

Width - 70inch
Depth - 13.8inch
Height - 23.2inch

Important – Please read these instructions fully before starting assembly

Safety and Care Advice

Important – Please read these instructions fully before starting assembly

• Check you have all the components and tools listed on the following pages.

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area, small parts could choke if swallowed.


• Make sure you have enough space to layout the parts before starting.

• During assembly do not stand or put weight on the product, this could cause damage.

• Assemble the item as close to its final position (in the same room) as possible.

• Assemble on a soft level surface to avoid damaging the unit or your floor.

• Parts of the assembly will be easier with 2 people.



• To reduce the likelihood of damaging your product please ensure that your power drill is set on a low torque setting.

Care and maintenance

• Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.

• From time to time check that there are no loose screws on this unit.

• This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints

• Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts

• Regularly check and ensure that all bolts and fittings are tightend properly.

WARNING
In order to help prevent overturning – please follow these instructions


To help prevent product toppling over please follow the below steps:-

Use the anti tip strap or wall fixing method provided (if applicable)
Do not allow children to climb or hang on the furniture
Do not open more than one drawer at a time
Do not place heavy items in the top drawers
Do not place heavy items on top of the furniture, unless the furniture has been designed for this purpose


Please note that only the anti tip strap is provided.
You will need to provide wall plugs and screws applicable for your wall type

Components - Panels


Please check you have all the panels listed below




1 (45.7 x 34.4 x 1.5cm) x1




2 (45.7 x 34.4 x 1.5cm) x1




3 (45.7x33.3x 1.5cm) x2




4 (174.2x34.8x 1.8cm) x1




5 (174.2x9x 1.8cm) x1



6 (56.5 x 34.9 x 1.8cm) x1




7 (56.5 x 34.9 x 1.8cm) x1




8 (46.4 x 23.2 x 0.27cm) x 2




9 (45.5cm) x2



10 (46.4 x 23.2 x 0.27cm) x 2



11 (178 x 35cm x 1.8cm) x1




12 (42.9 x 32 x 1.5cm) x2

Components - Fittings

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.


A  Male Camlock x 22	**B**  Female Camlock x 22	**C**  Dowel x 29
D  3.5*14mm Screw x 16	**E**  5*50mm Screw x 4	**F**  4*14mm Screw x 12
G  Adjustable Foot x 2	**H**  Protective Foot x 6	**I**  Hinge x 4
J  Back Panel Stiffener x 12	**K**  Door Bumper x 1	**L**  Wall Fixing Pack x 2


Tools required



Phillips screwdriver
(medium & large)

Ruler - Use this ruler to help correctly identify the screws






The screws length is measured from the head to the point (30mm screw shown).

Using Camlocks


Step 1

Connect the male camlock as directed in the assembly instructions using a screwdriver.



Step 2


Push the male camlock into the entry hole.



Step 3

Insert the female camlock as shown in the instructions.

Note: ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.




Step 4

Turn the female camlock clockwise with a screwdriver.

You should feel a click when the camlock is locked in place.

The joint is now secure.



Adjusting Hinges

Hinge adjustment:


a: To move the top panel up or down, loosen screws shown and move top panel to suit


b.To move the top panel in or out, loosen screws shown and move top panel to suit.

Retighten screws


C:To move the top panel left or right, adjust screws shown.


a:






b:






c:






Assembly Instructions





Assembly Instructions

Step 1




CAM-LOCK
Tighten until shoulder is flush with panel.Do not overtighten or undertighten(see example below)






Attach male camlock (A) to part (1, 2) with a screwdriver, then insert wooden dowel (C) into part (1, 2).

Step 2







Insert wooden dowel (C) into part (3).

Assembly Instructions

Step 3




B x 2




Attach part (1) to part (3), then insert and secure female camlock (B) to part (3) to lock it.

Step 4




B x 2




Attach part (2) to part (3), then insert and secure female camlock (B) to part (3) to lock it.


Assembly Instructions

Step 5




CAM-LOCK
Tighten until shoulder is flush with panel.Do not overtighten or undertighten(see example below)






Attach male camlock (A) to part (4) with a screwdriver.

Step 6







Insert wooden dowel (C) into part (5).

Assembly Instructions


Step 7







Insert wooden dowel (C) into part (4).

Step 8









Attach part (5) to part (4), then insert and secure female camlock (B) to part (5) to lock it.

Assembly Instructions


Step 9






Attach part (1, 2) to part (4) using screw (E) with a screwdriver.


Step 10



CAM-LOCK
Tighten until shoulder is flush with panel.Do not overtighten or undertighten(see example below)








Attach male camlock (A) to part (6, 7) with a screwdriver.

Assembly Instructions

Step 11


B x 4



Attach part (6) to part (3, 4, 5), then insert and secure female camlock (B) to part (3, 4, 5) to lock it.

Step 12


B x 4





Attach part (7) to part (3, 4, 5), then insert and secure female camlock (B) to part (3, 4, 5) to lock it.

Assembly Instructions

Step 13








Attach adjustable leg (G) to part(4) using screw(F) with a screwdriver.Insert protective feet(H) to part (5, 6, 7)


Step 14




Slide the back panel (8, 9, 10) into grooves as per diagram.

Assembly Instructions


Step 15





Insert wooden dowel (C) into part (1, 2, 6, 7).


Step 16




Attach long and short LED lights to part (11)
Note: you can find buckles and screws in the box of the fireplace


Assembly Instructions

Step 17




CAM-LOCK
Tighten until shoulder is flush with panel.Do not overtighten or undertighten(see example below)







Attach male camlock (A) to part (11) with a screwdriver.

Step 18








Attach part (11) to part (1, 2, 6, 7), then insert and secure female camlock (B) to part (1, 2, 6, 7) to lock it.


Assembly Instructions

Step 19



Attach plastic wedge (J) to back panel using screw (J) with a screwdriver.


Step 20



Use screw (D) to secure hinge (I) to door (12) with a screwdriver.


Assembly Instructions

Step 21



Use screw (D) to secure hinge (I) to part (6, 7) with a screwdriver. You may refer to page 4 about how to adjust hinge.Attach door bumpers (K) to part(3).


Step 22



Before attaching fireplace to TV stand, unscrew four silver screws on the both sides of fireplace, and unscrew two screws on the front.


Assembly Instructions


Step 23



Carefully remove the front glass, and place it on a soft and clean surface.

Step 24







Assemble the fireplace insert to the stand and secure it with screw(F).

Assembly Instructions


Step 25





Attach the glass front to the fireplace.


Step 26



Fix the tempered glass with 2pcs of 4x8mm screws.

Assembly Instructions


Step 27



Connect the LED lights with the power cables.

Assembly Instructions

Step 28



Level the furniture by adjusting the height of the feet

Assembly Instructions

Step 29

The unit is floor standing, but it is recommended that the unit is secured to the wall.

1. Move the unit into desired position.

2. Mark the wall with a suitable scribe the position of the fixing holes.


Warning:
Before driling,check wall for hidden pipes and cables.


3. Drill holes and insert 2 x wall plug

4. Attach 2 x Wall Straps to to the top of the unit using 2 x Washers and 2 x Screws

5. Secure the straps to the wall using 2 x Washers and 2 x Screws

Note: To hide the straps behind the unit, drill the holes lower than the top of the unit





Assembly is complete.

A Guide to Wall Mounting & Fixings

Important note:

If plastic wall plugs (rawl plugs) are supplied with your product, e.g.:



- these are only suitable for use in masonry walls.

If you are in any doubt about the correct wall plugs for your wall, seek professional advice.

Failure of the product due to using the incorrect fixings is the responsibility of the installer.

Important: when drilling into walls always check that there are no hidden wires or pipes etc.

Make sure that the screws and wall plugs being used are suitable for **supporting your unit. Consult a qualified tradesperson if you** are unsure.


Hints:

1: General rule: always use a larger screw and wall plug if you are not sure.
2: Ensure you use the recommended drill bit to match the wall plug and hole size.
3: Ensure you drill the hole horizontally; do not force the drill or enlarge the hole.
4: Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.
5: Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

Types of walls


You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

No.1 “General Purpose” wall plug




Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

No.3 “Cavity Fixing” wall plug




For use with plasterboard partitions or hollow wooden doors.

No.5 “Hammer Fixing” wall plug




For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

No.2 “ Plasterboard” wall plug




For use when attaching light loads onto plasterboard partitions.

No.4 “ Cavity Fixing – Heavy Duty” wall plug



For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.

No.6 “ Shield Anchor” wall plug – heavy loads



For use with heavier loads such as TV and HiFi speakers and satellite dishes etc.

Care & Maintenance

Safety: always check the fitting and location to ensure your safety in and around the home.

Fitting: from time to time check the fitting to ensure the wall plugs or screws do not become loose.