Read These

Instructions

Before Using

This Unit!

Save These

Instructions

RETURNS & WARRANTY

Should your unit not work or is damaged when you first take it out of the box, please return the unit immediately to the place of purchase. Should you have any other questions about the unit, please contact us at the numbers below between the hours of 8:00 am to 5:00 pm, Monday through Friday, Pacific Standard Time.

This appliance is not intended for use by persons (including children)with reduced physical,sensory or mental capabilities,or lack of experience and knowledge,unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
Children should be supervised to ensure that they do not play with the appliance.

This appliance is designed and built to provide many years of satisfactory performance under normal household use. The distributor pledges to the original owner that should there be any defect in material or workmanship during the first 90 days of purchase, we will repair or replace the unit at our option. Our pledge does not apply to damages caused by shipping, mishandling or unit being dropped. A product deemed defective either from manufacturing or being mishandled is up to the distributors decretion. To obtain service under this warranty, return this unit to The Helman Group, Ltd. at the address above, shipping prepaid. You must also include a copy of the original receipt along with your name, address and phone number. Include a description of the defect along with the date you purchased the product.

Please read these instructions carefully. Failure to comply with these instructions, damages caused by improper replacement parts, abuse or misuse will void this pledge to you and is being made in place of all other expressed warranties.

COTTON CANDY MAKER

INSTRUCTION MANUAL

INTRODUCTION

Thank you for purchasing The COTTON CANDY MAKER This nostalgic looking cotton candy maker resembles the early 1900's carnival and circus style cotton candy carts.

The COTTON CANDY MAKER is only designed in appearance to look like the nostalgic style cotton candy carts, however, it is a technologically advanced cotton candy maker.

The whole family will enjoy the COTTON CANDY MAKER Please take care of your machine by following these instructions and precautions.

Display your COTTON CANDY MAKER with pride and enjoy some good old fashioned carnival style fun!

You can use a variety of flavored sugars with COTTON CANDY MAKER

- Bubble Gum
- Boo Blue
- Spooky Fruiti
- Silly Nilly

HERE'S A TIP – You can use regular household granulated sugar in your COTTON CANDY MAKER . To add a little flavor and color, mix a pinch of your favorite pre-sweetened Kool-Aid® to the sugar. Imagine the variety of flavors you can make and the fun you'll have!

The COTTON CANDY MAKER is designed for kitchen use but can be used anywhere such as;

- **Family Room**
- **Dorm Rooms**
- **Office**
- **Club House**
- **Anywhere people gather to have fun**

And more…

INTRODUCTION

Now you can enjoy delicious cotton candy…

- **Watching TV or a movie at home**
- **For Birthday Parties**
- **Kids Sleep-overs**
- **After school**
- **Barbecues**

And more…

The COTTON CANDY MAKER is easy to use, just follow these simple instructions.

USING YOUR COTTON CANDY MAKER

Your COTTON CANDY MAKER is already fully assembled. Follow the cleaning instructions on page 8. Wash in warm water, rinse and dry thoroughly. **(Figure A)**.

After cleaning and thoroughly drying the bowl, return to base making sure it is LOCKED in to position. Align the metal tabs on the base unit with the plastic tabs on the bowl. The tabs on the bowl will fit under the metal tabs as you turn the bowl counterclockwise to LOCK. Make sure it is secured and locked into position. To remove, turn clockwise to UNLOCK. **(Figure D)**

Return the extractor head assembly making sure that the grooves are properly aligned to fit over the pegs on the stem. **(Figure B & C)**

Now you are ready to enjoy tasty, fluffy cotton candy from your COTTON CANDY MAKER

First, find a stable surface near an electrical outlet before starting. (Make sure your cord is away from any water source. If needed, it is acceptable to use an extension cord.)

1. Plug in unit at the OFF position.

2. Turn unit to ON position and allow to run for at least 5 minutes. This will allow it to warm up. Then switch to OFF.

3. Measure level tablespoon of sugar with measuring spoon supplied with your COTTON CANDY MAKER
Pour sugar into center receptacle **(Figure F)**. Switch to ON position. **(Figure G)**

4. Your COTTON CANDY MAKER will spin the sugar into a flossy sweet treat that you collect on the paper cone by spinning the cone as it circles the bowl…just like at the carnival!

5. When you can visually see the cotton candy 'web' begin, collect the cotton candy on the cone by holding the cone vertically. Rotate the cone with your fingers while you circle the bowl. Once cotton candy has collected on the cone then hold the cone in a horizontal position over the extractor head still rotating the cone with your fingers. Continue turning the cone with your fingers while the cone is in the horizontal position and move from side to side making sure you are collecting all the cotton candy. **(Figure H)**

6. Turn the unit Off when all the sugar has been dispensed. Once the extractor head has come to a complete stop, you can pour another measure of sugar in the extractor head and begin again. The cotton candy should been flowing more quickly as the unit should be sufficiently warmed up.

✧ NOTES

For optimum results - Be sure to turn unit ON and allow it to run for at least 5 minutes before starting. This allows the unit to properly warm up before beginning to actually spin the cotton candy. Only add sugar to the extractor head when it has come to complete stop. Never use ingredients other than pure granulated sugar. This will cause clogging. DO NOT overfill the sugar receptacle.

By following these simple instructions, using your CANDY MAKER will be fun for kids of all ages…young or old by bringing a carnival atmosphere to any occasion.

IMPORTANT PRECAUTIONS:

21. Appliance Specifications:
    220-240V
    50Hz
    500W

Important Precautions to Remember:

A. NEVER immerse in water.

B. NEVER use near water.

C. NEVER use an abrasive sponge or cloth.

D. NEVER use a scouring pad on the unit.

E. NEVER leave unit unattended while in use.

F. NEVER place anything other than the intended sugar in the extractor assembly head.

G. Unplug unit from outlet when not in use and when cleaning.

H. DO NOT operate this appliance with a damaged cord or plug or in the event the appliance ever malfunctions.

I. DO NOT put in dishwasher.

J. Keep out of reach of children.

IMPORTANT SAFE GUARDS

10. DO NOT place on or near a hot gas or electric burner, or in a heated oven.

11. Extreme caution must be used when moving this appliance.

12. DO NOT use the appliance for other than its intended use.

13. DO NOT leave unit unattended while in use or when plugged in to an outlet.

14. Check inside heating element compartment for foreign objects before switching to ON position.

15. Heating element in center can get hot. **Avoid contact until cool.**

16. A short power supply cord is provided to reduce the risk resulting from becoming entangled or tripping over a long cord.

17. Longer detachable power supply cords can be used if care is exercised in their use.

18. The marked electrical rating of an extension cord should be at least as great as the electrical rating of the appliance.

19. This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electrical shock, this plug is intended to fit into a polarized outlet only one way.

20. Keep hands away from the machine when it is in the ON position and is spinning.

SAVE THESE INSTRUCTIONS!

Figure F

Figure G

Figure H

CLEANING

1. Make sure unit is unplugged and has had time to cool down before cleaning.

2. After cooling, remove the extractor head assembly by pulling straight up. UNLOCK bowl by turning clockwise and remove. **(Figure B & C & D)** Wash both in warm water, rinse and dry.

3. Use a slightly damp, non-abrasive sponge or non-abrasive towel to wipe clean the outside of the unit, wipe with a non-abrasive towel to dry.

The COTTON CANDY MAKER breaks down to – cart body, bowl, and extractor head assembly for easy cleaning. **(Figure E)**

NOTE: Cotton candy is made by heating sugar. This turns sugar into a liquid form. Then the sugar liquid is forced out of tiny holes in the extractor head by centrifugal force as the extractor head spins. As the liquid sugar hits the air, it returns to a solid fluffy material that adheres to a paper cone.

It is very important that the unit be cleaned properly after every use. If it is not, the holes will get clogged and sugar will not be able to sift through the tiny holes properly.

IMPORTANT SAFE GUARDS

When using electrical appliances, basic safety precautions should always be followed, including the following:

1. Read all instructions before operating this appliance.

2. DO NOT TOUCH the hot surfaces. Use handles or knobs.

3. To protect against electrical shock do not immerse cord, plug or any part of this unit in water or other liquids.

4. Close supervision is necessary when any appliance is used by or near children.

5. Unplug from outlet when not in use and before removing parts for cleaning.

6. DO NOT operate any appliance with a damaged cord or plug or if the appliance has been damaged in any manner. Return the appliance to the nearest repair shop for examination or repair or send back to company as stated in this booklet in the warranty.

7. The appliance manufacturer does not recommend the use of accessory attachments. This may cause injuries.

8. DO NOT use outdoors.

9. DO NOT let the cord hang over the edge of table or counter tops or touch hot surfaces.

Figure B
Removing the Extractor Head Assembly

Figure C
Extractor Head-showing groove that fits over stem

Figure D
Metal tab on unit fitted with plastic tab on bowl to Lock and Unlock

Figure E
Breaks down to cart body,bowl and extractor head

A Little Background on Cotton Candy

It was a little tough to trace the actual history of this fluffy carnival and circus treat…there were a few conflicting stories. So I'll provide you with what I discovered and you can choose the story you like best.

The earliest I could trace COTTON CANDY back to was 1897. Two Tennessee candy makers, William Morrison and John C. Wharton from Nashville, invented the first electric machine that allowed crystallized sugar to be poured onto a heated spinning plate then forcing it through tiny holes thus creating, as they called it, Fairy Floss. They took their discovery to the St. Louis State Fair in 1904. At the fair, they sold the Fairy Floss in chipped-wood boxes for 25 cents each.
-They sold 68,655 boxes.

The city of New Orleans claims that Josef Delarose Lascaux, a dentist, invented cotton candy and the cotton candy machine.

. The last interesting story is that cotton candy first appeared at the Ringling Bros.Circus in 1900 and Thomas Patton received a patent on the cotton candy machine in 1900.

Cotton candy was originally called Fairy Floss (this ties in to the Morrision/Wharton story). The British call it candy floss and here in America, we started calling it cotton candy in the 1920s.
If you or anyone you know can provide information on the history of cotton candy we'd love to hear from you.

Figure A