
Household Treadmill Instruction Manual



Contents

1. Cover & Pre-Use .....(2)

2. Safety Precautions .....(3)

3. Names of Each Part and Accessories.....(4)

4. Assembly Instructions .....(6)

5. Display & Operation .....(8)

6. Exercise Guidance & Walking .....(10)

7. Maintenance .....(12)

8. Troubleshooting.....(16)

9. Product Specifications & Warranty.....(17)

Caution To ensure safe use, please read this manual carefully and fully understand the contents before operation.

1. Cover & Before Use

Thank you very much for your purchase.

Please contact us if any issues such as damage during transportation, missing parts, error code display, or malfunctions occur. We will provide you with a satisfactory solution.

E-mail: service_sports@163.com

Please provide:

·Order Number

·Details of Product Issues

(Attach relevant images/videos if applicable)

Before using this product, be sure to read the "Safety Precautions" carefully and handle it correctly.


2. Safety Precautions

Please read the following symbols and instructions carefully, and use the product safely and correctly.

Icon	Meaning	Specific Precautions
	Warning	**Electric Shock and Fire Prevention** · Do not use in wet or humid areas under any circumstances. · Do not damage the power cord or place it near heat sources. · Be sure to unplug the power plug during maintenance. **Handle with at least two adults.** · Be sure to have at least two adults move or unpack the main unit.
	Prohibited	**Injury Prevention** · Please ensure children and pets do not play around the machine. **Prohibited Forced Operation** · Do not disassemble or modify the product under any circum stances – this may cause serious malfunctions or accidents. **User's Health** · Individuals with chronic illnesses, pregnant individuals, or the elderly should consult a physician before use. · If you feel unwell during training, stop immediately.
	Caution	**Power Check** · Do not bend the power cord or place it near heat sources. before use, check that the power plug is firmly connected. **Correct Installation and Use** · Install on a flat and stable surface. · Ensure adequate space. · Use a dedicated power outlet. Do not share it with other devices. **Health Status Check** · Individuals with chronic illnesses or pregnant individuals should consult a physician before use.

3. Names of Each Part and Accessories



● Product Diagram



Note: Our products are constantly being improved and may be modified without prior notice. We appreciate your understanding.

● Parts List

Before use, please check that all accessories are included.


No.	List	Part Name	Qty
1		Treadmill machine	1
2		Hex Wrench	1
3		Remote Control	1
4		Safety Key	1
5		Safety Key Cord Clip	1

4. Assembly Instructions

Assembly work must be performed by two or more adults.


STEP 1

1. Choose flat ground to place the Walking Treadmill.



STEP 2


1. Power on and start to running.




Installation has been completed!

Safety Key Installation:

1. Place the small round end of the safety key (4) onto the corresponding position on the motor cover.




2. Attach the safety key cord clip(5) to the right edge of the running deck as shown.
3. Open the clip, pass the safety key cord through it, then close the clip to secure the cord.
4. Attach the clip on the other end of the safety key to your clothing. Ensure the safety key is properly secured before operating the treadmill.




5. Display and Operation

1. Display Window



Display	Content
◆ TIME	Exercise Time or Countdown Remaining Time
◆ SPEED	Current Speed (1 - 8 KM/H / 0.6 - 5 MPH)
◆ DISTANCE	Distance Traveled or Countdown Remaining Distance
◆ CALORIE	Calories Burned or Countdown Remaining Calories

Remote:



Speed Up.

Press the button to run which will automatically stop when it reaches the set value.

•Time Countdown Mode: The window shows 30:00 minutes, set the time (5:00 to 99:59 minutes)with the speed keys.

• Distance Countdown Mode:The window shows 1 km, set the distance (0.5 to 99.99 km) with the speed keys.

• Calorie Countdown Mode: The window shows 50 kcal, set the target (10 to 999.9 kcal) with the speed keys.

Long Press: Stop
Short Press: Start / Pause

Speed Down.

6. Exercise Recommendations and Guidelines

◆Warm-up

Before using the unit, please perform a 5-10 minute warm-up.

◆Breathing

Do not hold your breath during exercise. Coordinate your breathing with your movements. If your breathing becomes too labored, stop exercising immediately.

◆Frequency

Allow 48 hours of rest between training the same muscle groups – that is, please train the same groups every other day.

◆Load

Determine training intensity based on your individual physical condition, then proceed with training following the principle of progressive overload. At the start of training, muscle soreness is normal. The soreness will subside as you continue training.

◆Diet

To protect your digestive system, exercise at least 1 hour after meals. After training, wait at least 30 minutes before consuming a meal. Do not consume excessive water during exercise – especially avoid drinking large amounts of water at once – to avoid increasing the burden on your heart and kidneys.

◆Stretching Exercises


No matter how fast you run, it is advisable to perform stretches first. Warmed-up muscles are easier to stretch, so warm up for 5-10 minutes. Then, stop briefly to perform the following 5 stretches. Hold each stretch for 10 seconds or more per leg, and repeat them again at the end of your workout.

1. Forward Bend Stretch

Bend your knees slightly, slowly bend forward, relax your back and shoulders, and reach for your toes with your hands. Hold for 10-15 seconds, then relax. Repeat 3 times (see Figure 1).

2. Hamstrings Stretch

Sit on a clean mat, extend one leg. Bend the other leg inward and press it firmly against the inner side of the extended leg. Reach for the toes with your hands. Hold for 10-15 seconds, then relax. Repeat 3 times per leg (see Figure 2).



3. Calf and Achilles Tendon Stretch

Place both hands on a wall or table, step one leg back, and stand. Keep the back leg straight, heel flat on the floor, and lean your weight forward toward the wall or table. Hold for 10-15 seconds, then relax. Repeat 3 times per leg (see Figure 3).

4. Quadriceps Stretch

Use your right hand to balance on a wall or table, reach back with your left hand, grab your left ankle, and slowly pull it toward your glutes. Hold the position for about 10-15 seconds when you feel a full stretch in the front of your thigh. Then relax. Repeat 3 times per leg (see Figure 4).

5. Adductors Stretch (Inner Thigh Muscles)

Sit with the soles of your feet together, pointing your knees outward. Hold your feet with both hands and pull them toward your body. Hold for 10-15 seconds, then relax. Repeat 3 times (see Figure 5).

7. Maintenance

Running Belt Adjustment Method

This product allows you to adjust the tension of the running belt by turning the belt adjustment bolts located at the rear part of the running deck.


Check: Turn on the power, run the belt at a speed of approximately 3-5 KM/H , and check if it runs straight.

Please perform the adjustment with the power turned off and the plug unplugged.
Adjustment Tips: For each adjustment, turn no more than a 1/4 rotation.
After adjustment, turn on the power, run it at low speed, and check the condition.

Case 1: If the belt is shifting to one side


Symptom: The belt shifts left or right, rubs against the main unit frame, and produces abnormal noise.

1




Check the deviation direction: Check which direction the belt is shifting.

2



Tighten the opposite side: If the belt shifts to the right, use a hex wrench to turn the left adjustment bolt clockwise by 1/4 rotation and tighten it. If it shifts to the left, turn the right adjustment bolt clockwise by 1/4 rotation and tighten it.

3




Tighten the opposite side: If the belt shifts to the left, use a hex wrench to turn the right adjustment bolt clockwise by 1/4 rotation and tighten it. If it shifts to the right, turn the left adjustment bolt clockwise by 1/4 rotation and tighten it.

Case 2: If the belt slips or pauses


Symptom: While walking or running, the belt slips under your feet, or the belt stops even though the motor is running.

1




Tighten both sides evenly: Use a hex wrench to tighten the left and right adjustment bolts at the rear part of the main unit evenly, turning each clockwise by 1/4 rotation at a time.

2



Check: Actually run it at low speed and check if the slipping has been resolved.

3




Repeat: If the slipping persists, repeat evenly tightening both sides

Case3: If the belt is over-tightened


Symptom: The belt is extremely stiff with no slack, and the motor feels overloaded.

1




Loosen both sides evenly: Use a hex wrench to loosen the left and right adjustment bolts at the rear part of the main unit evenly, turning each counterclockwise by 1/4 rotation at a time.

2



Check the slack: After adjustment, when the unit is stopped, lift the center of the belt and check if it rises about 3 cm to verify proper tension.

3



Repeat: If the tension is too tight, repeat this process.

▼ Click here for the detailed video of the adjustment method ▼

8. Troubleshooting

NO.	Error code	Description	Maintenance
1	E01	Upper and Lower Control Link Failure	1. Check if the connecting cable between upper and lower controls is properly connected. 2. Replace the connecting cable.
2	E04	Speed communication cable disconnected	1. Check if the connecting cable between upper and lower controls is properly connected. 2. Replace the connecting cable.
3	E05	Software Overcurrent	Power off and then restart the power supply.
4	E06	Protection against motor stall	Check if any foreign object jams the motor and prevents it from rotating.
5	E07	Safety Lock Dislodged	Check that the safety sensor is properly aligned with the safety lock magnet.
6	E0A	Incorrect Current Setting	Replace the controller.
7	E0C	Hardware Overcurrent	Power off and re-power on.
8	E0D	Overvoltage	1. Unstable power grid voltage on user side. 2. Replace the controller.
9	E0E	Undervoltage	Check if the input voltage matches the rated voltage of the controller.
10	E0F	Check for phase loss of power supply.	Check if the motor cable is securely connected.

9. Product Specifications and Warranty

Item	Specifications
Rated Voltage	220-240 V
Frequency	50 Hz
Speed Range	1-8 KM/H (0.6-5 MPH)
Max User Weight	159KG/350LBS
Max Power	3.0 HP
Warranty Period	For 1 year from the date of purchase

● Note:

A purchase certificate (such as a receipt) is required when availing of the warranty.Please be sure to keep it.Please dispose of this product in accordance with the waste classification of your local area.

Warranty Coverage: 1-year parts replacement

Customer Support:

Please contact us. 100% Satisfaction Guarantee	
✓	We have professional customer service staff to answer your questions within 24 hours. If you have any questions, please feel free to contact us.
✓	Return Policy: 30-Day Hassle-Free Returns & Exchanges.
✓	Customer Service: A service team providing personalized solutions to ensure 100% customer satisfaction.
✓	Dedicated Maintenance Service: As a commitment to quality and durability, we provide free maintenance tools for orders placed within 6 months.

E-mail: service_sports@163.com

For inquiries regarding this product, please contact us via email.