USER'S MANUAL：

This product requires 3X AA batteries 1.5V (not included) TRYME includes 2X CR1620 3V button cell batteries for shelf sales demonstration purposes only.

-Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children.Do NOT dispose of batteries in household trash or incinerate.Even used batteries may cause severe injury or death.

-Call a local poison control center for treatment information.

-Do not force discharge, recharge disassemble, heat above 125 ℃ or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns.

-Non-rechargeable batteries are not to be recharged.

-Ensure the batteries are installed correctly according to polarity (+ and -).

-The battery of try me can no be replaced.

Do not mix old and new batteries.different brands or types of batteries,such as alkaline, carbon-zinc, or rechargeable batteries.

Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations.

Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product,remove the batteries,and keep them away from children.

TO REPLACE BATTERIES:

1.Locate battery compartment on the bottom.

2.Turn off switch.

3.Unscrew battery compartment door with a screwdriver.

4.Replace with 3 X AA size batteries observing the polarity drawing inside case.

5.Replace the cover and turn switch back to “ON” position.

INGESTION HAZARD: This product contains a button cell or coin battery.

DEATH or serious injury can occur if ingested.

A swallowed button cell or coin battery can cause Internal Chemical Burns in as little as 2 hours.

KEEP new and used batteries OUT OF REACH Of CHILDREN

Seek immediate medical attention if a battery is suspected to be swallowed or inserted inside any part of the body.