

INSTALLATION
Product Manual

Version: 520182US-01-26A-PR




IMPORTANT INFORMATION!

please read the entire manual before starting to assemble and/or using this product.follow the manual thoroughly and keep it for further reference.




AVOID SCRATCHES!

In order to avoid scratching this furnuture should be assembled on a soft layer-could be a rug.



IMPROVE EFFICIENCY !

Try to find a partner to install with you, which can speed up the installation efficiency and shorten the time.



ANTI-TOPPLE WARNING !


Overturned furniture can cause serious or fatal crush injuries. To prevent tipping over, be sure to use the wall attachment, if not included with this product. Please purchase the wall attachment that fit your wall. If unsure, seek professional advice. Please read and follow each step of the instructions carefully.

IMPORTANT !

It is important that any product which is assembled using any kind of screw is re-tightened 2 weeks after assembly,and once every 3 months - in order to assure stability through-out the lifespan of the product.



For regular maintenance and cleaning of the product, for the frame, please use a rag dipped in neutral detergent to fully wipe it, and then dry it with a clean rag.For glass materials, wipe with a rag dampened with water glass cleaner, and then dry with a dry rag.


Do not use an electric screwdriver, and do not use too much force when installing, because the board is easy to break.















When installing, please carefully confirm whether each screw corresponds to the manual, accessories with similar shapes can be distinguished by size


A x 44	B x 44	C x 58	D x 2	E x 4
				
∅7 x 35 mm	∅15 x 9.5 mm	∅8 x 45 mm	∅8 x 80 mm	∅8 x 25 mm

F x 40	G x 4	H x 8 4	J x 16	K x 6
				
∅8 x 16 mm	M8 mm	M8 mm	∅4 x 12 mm	∅6 x 25 mm

L x 44	M x 12	N x 2	O x 10	P x 2
				
∅5 x 15 mm	∅5 x 50 mm	N-1 N-2		

Q x 1	R x 3	S x 2	T x 4	U x 4
				
			100 x 75 mm	

V x 6	W x 2
	




⚠WARNING


Children have died from furniture tipover.To reduce the risk of furniture tipover:

- ALWAYS install Anti-tip device provided.
- NEVER put a TV on this product.
- NEVER allow children to stand,climb or hang on drawers,doors,or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.


This is a permanent label.
Do not remove!





1

C x 10	H x 18	
		
∅8 x 45 mm	M8 mm	


Secure part 28 to part 1, 6, 5, and 10 using washer (H) and screw (C).






2

C x 2	D x 2	H x 4	G x 4	R x 3	
					
∅8 x 45 mm	∅8 x 80 mm	M8 mm	M8 mm		

Secure part (R) to two part 24 using washer (H), screw (C) and nut (G).
Secure part (R) to two part 25 using washer (H), screw (D) and nut (G).




3

C x 24	F x 16	H x 4 0	T x 4	U x 4	
					
Ø8 x 45 mm	Ø8 x 15 mm	M8 mm	100 x 75 mm		


J x 16

Ø4 x 12 mm

Secure part (T) to two part 6, 7, 8, 9, and 10 using screw (F).
Secure part (U) to two part 1, 2, 3, 4, and 5 using screw (J).
Secure part 24 and 25 to the component using washer (H) and screw (C).




4


C x 16	H x 16	
		
Ø8 x 45 mm	M8 mm	

Secure part 26 to part 11, 15, and 12 using washer (H) and screw (C).


Please note that the hook and loop fastener should be installed with the loop side up



5

M x 8	V x 4	
 ∅5 x 50 mm		

Secure part (V) to two part 11 and 12 using screw (M).




6

C x 6	H x 6	Q x 1	
∅8 x 45 mm	M8 mm		

Secure part (Q) to part 13 and 14 using washer (H) and screw (C).


Please ensure the heights of Q and V are consistent



7

M x 4	V x 2	
∅5 x 50 mm		

Secure part (V) to part 13 and 14 using screw (M).




Please ensure the heights of Q and V are consistent.

8


F x 16





∅8 x 16 mm




Connect part 6, 10, 13, 14 to part 11, 12, 13, and 14 using screw (F).



9

E x 4	P x 2	S x 2	
 ∅8 x 25 mm			

Secure part (P) and (S) to part 27 using screw (E).




10

F x 8




∅8 x 16 mm



Secure part 27 to part 7, 9, 13, and 14 using screw (F).


Adjust the middle?leg height of Part P accordingly



Rotate the bottom device and let it fall to the ground


11

Place part 23 in the appropriate position.





12

A x 24




∅7 x 35 mm





Screw self-tapping rod (A) onto part 18 and 19.




x2


13

B x 24




∅15 x 9.5 mm






Connect part 21 and 22 to part 18 and 19, then tighten by turning cam lock (B) clockwise.



14


Insert part 20 along the available the slots.




x2


15

A x 20




∅7 x 35 mm





Screw self-tapping rod (A) onto part 17.





16

B x 20




∅15 x 9.5 mm







Connect part 17 to part 18, 21, and 19, then tighten by turning cam lock (B) clockwise.



17

L x 40	O x 10	
 ∅5 x 15 mm		

Secure wheel (O) to part 21 and 22 using screw (L).




18


K x 6






∅6 x 25 mm




Secure part 16 to part 18 using screw (K).




19

L x 4	N x 2	W x 2	
 ∅5 x 15 mm			


Secure bracket (W) to part 1 and 5 using screw (L).
Install the anti-tip device as shown.






20

Push the two drawers in place.



21



WARRANTY

WARRANTY CLAIMS

•There is a 30-day warranty for broken furniture or any other problems that do not work properly. The warranty will start from the date of purchase which must be verified by proof of purchase.

•Before making a claim, we may be able to answer your query, simply call us. Please leave your purchase order number, along with some details of the problem, if you want a replacement part. We will arrange within 48 hours. If there is out of stock, we will reply with a shipping date.

•The product must be used in accordance with the instructions provided. For health reasons.

•For other reasons, if the furniture needs to be returned, it must be cleaned and dried and operated within 30 days of receipt.

Type of Warranty Claim

•Failure to follow the furniture instructions will invalidate the warranty. Attention please.

•Does not include damage during installation, but includes damage during transportation.

Scope of responsibility

•Shall not bear any responsibility for misuse or user damage and / or loss of parts during the installation of furniture.

•After using, the damage and scratches of the furniture are not covered by the warranty.

The Warranty Relates to All Bought in The Us and Covers The Following Areas

•Sheet parts: 1 month from the date of purchase.

•Electrical parts: 1 month from the date of purchase.

RETURNS

CHANGED YOUR MIND AND NEED TO RETURN YOU ITEM?

PLEASE FOLLOW THE BELOW INSTRUCTIONS:

- If you have purchased and have simply changed your mind, follow the retailer's instructions for returns.

DEFECTIVE ITEMS

- If your item is defective in any way, i.e. it doesn't work but you can't identify why, in the first instance, please call us.

DAMAGED ITEMS

- If you receive an order with obvious shipping damage from the retailer, then we suggest the delivery is refused. If the delivery has been accepted and then shipping damage is found, please follow the specific instructions advised by the retailer.
  In all circumstances please save all packaging material and paperwork for the order. Please be aware that if you dispose of packaging material or attempt to return the merchandise without contacting the fulfiller, you jeopardise your chances of making a claim, and you may not receive a credit for the return.

AFTER-SALES CONTACT


adelahu@fufugaga.com


208-820-0068