
Assembly Instruction

CBN123



Warm Reminder

If you experience any issues with our product (including missing parts, damage, or not meeting expectations), please contact us. We'll ensure satisfactory assistance within 24hours.

Email: vipservice03@yeah.net

EN

General Guidelines

- Please read the following instruction carefully and use the product accordingly.
- Please keep this manual and hand it over when you transfer the product.
- This summary may not include every detail of all variations and considered steps. Please contact us when further information and help are needed.


Notes

- The product is intended for indoor use only. The product must be assembled and used in accordance with the provisions of the manual. Personal injury and/or damage to product may occur if products are used outside of their intended purposes and/or if products have been changed/modified from their original design. The seller does not assume any responsibility or liability with respect to any injury/damage caused by incorrect assembly or improper use.
- Avoid long-term exposure to humid environments to prevent mildew.
- Keep the product away from fire sources and high temperatures. Do not expose the product to direct sunlight.
- Do not place any hot objects on the surface of the product.
- If there are any defective or missing parts after unpacking, please cease assembly immediately and contact us.
- Please assemble the item on a spacious surface and do not place the unwrapped product directly on the ground to avoid product damage.
- Please do not stand or sit on the wooden boards.
- Please wear gloves during the assembly and/or disassembly process to avoid scratches from any sharp edges.
- Please match the corresponding part and fitting based on the part number in the manual.
- If the part does not match with the fitting, please check the piece as specified in this manual.
- During assembly, first loosely align all screws with the corresponding pre-drilled holes and then tighten the screws one by one.
- Periodically inspect screw tightness while the product is in use. If necessary, retighten to ensure structural integrity.
- If you accidentally spill water or another liquid on the surface, immediately wipe clean with a dry towel.
- Please keep the product away from sharp, pointed objects and corrosive substances to prevent product damage.
- Please place this item on level, solid ground during use.


Warnings


- During assembly, keep all small parts out of the reach of children. It may be fatal if swallowed or inhaled.
- Children should not climb or play on the product in order to avoid tipping over the furniture and causing serious injury.
- To avoid the potential dangers of suffocation, please keep all parts and packaging (film, plastic bags, foam, etc.) away from babies and children.
- Keep sharp objects and corrosive items away from the product to avoid any damage or injury.
- Do not shake or move violently during use to avoid tipping over the product.


Parts List(EN)















Parts List(EN)













①  1PCS	②  1PCS	③  1PCS	④  1PCS
⑤  1PCS	⑥  2PCS	⑦  1PCS	⑧  2PCS
⑨  2PCS	⑩  2PCS	⑪  2PCS	













Parts List(EN)










A  ϕ6*40mm 8+1PCS	B  ϕ15*9.5mm 8+1PCS	C  ϕ8*30mm 4+1PCS
D  Ø15*5mm 4+1PCS	E  Handle 2 sets	F  Left Right 2 sets
G  Ø21mm 8+2PCS	H  2 sets	I  ST5*40mm 20+2PCS
J  M3 1 PCS	K  Ø3.5*12mm 32+2PCS	L  1PCS
M  4 PCS	N  4 PCS	O  4 PCS

Instructions For Fastening
CAM-BOLT and CAM-LOCK




CAM-BOLT




CAM-LOCK


Tools Required




INSERTING AND TIGHTENING CAM-BOLT



Place Cam-bolt on pre-drilled hole and screw in vertically




Shoulder is flushed (on the same level) with the panel.



Shoulder is above the panel.

Place Cam-bolt on the designated pre-drilled holes on the panel. Use a Phillips Screwdriver to screw-in Cam-bolt vertically until shoulder is flushed (on the same level) with panel.

INSERTING CAM-LOCK




Insert Cam-lock with arrow align to Cam-bolt head

CORRECT

WRONG

Align the arrow on the Cam-lock to the Cam-bolt head and insert the Cam-lock. Ensure Cam-lock is fully inserted.

TIGHTENING CAM-LOCK




Use a Flat-head Screwdriver to turn Camlock clockwise so it locks onto the head of the Cam-bolt. Turn until it is snug (about 3/4ths of a turn) -- over-tightening could damage Cam-lock or/and Cam-bolt.

Assembly Steps(EN)

Step 1

Note: Please knock the accessory into the groove of the board.




Note: The "M" accessory needs to be distinguished from top to bottom, with the holed side facing down!!!

	Mx4pcs

Step 2


Note: Please knock the accessory into the groove of the board.





	Nx4pcs


Assembly Steps(EN)

Step 3




	Lx1pcs
	Ax8pcs
	Cx4pcs



Step 4



	Lx1pcs
	Bx2pcs

Step 5






	Ix6pcs
	Jx1pcs

Step 6

Pay attention to the direction of the holes


Please note: The panel marked with the number "6" should be assembled with the side that has the holes facing up.





	Ix4pcs
	Jx1pcs


Assembly Steps(EN)

Step 7




	Ix10pcs
	Jx1pcs

Step 8



	Lx1pcs
	Bx6pcs


Step 9



	Dx4pcs
	Gx8pcs


Note: The pegs can be directly hammered into the board.

Step 10




	Lx1pcs
Right	Fx2pcs
Left	Fx2pcs
	Kx4pcs

Step 11




	Lx1pcs
	Kx12pcs


Step 12




	Lx1pcs
	Kx8pcs

Step 13




	Lx1pcs
	Ex2sets

Step 14




	Lx1pcs
	Ox2pcs
	Kx2pcs

Step 15




	Lx1pcs
	Kx2pcs

Step 16




	Lx1pcs
	Ox2pcs
	Kx2pcs

Step 17




	Lx1pcs
	Kx2pcs

Step 18





	Lx1pcs
	Hx2sets

Step 19



Step 20





Final