SAFETY ADVICE AND WARNINGS:

1. This battery operated item is for indoor use only.
2. Batteries not included.
3. This product requires 3 x AA or 3 x AAA1.5v batteries.
4. Remove batteries when not in use.

CAUTION:

1. Batteries are to be inserted with the correct polarity.
2. Never mix old & new batteries (replace all batteries at the same time)
3. Use only batteries of the same or equivalent type.

USING USB CABLE(INCLUDED):

1. If continuous electrical use is desired, plug included USB cable into AC port in back of the device.
2. Use any USB-A wall adapter rated to 1 amp.(not included) Plug into wall to power device.
3. USB cable can be plugged into any USB-A compatitble ports including: computers, laptops, and power banks.

WARNING

1. This is not a toy. Handle it with care.
2. Do not use solvents or abrasive cleaners to clean this product. If cleaning is required, use only a soft damp cloth.
3. Never try to disassemble or repair this product.
4. For long-term storage, wipe it clean, take out the batteries and store indoors.

Operating instructions

1. Remove battery compartment from base of product.
2. Insert 3 x AA batteries and then fix the compartment cover back on tight.
3. Push the switch to the on position, the lights will come on & the glitter swirls around.
4. To turn off push the switch to the off position, the lights will turn off & the glitter will stop swirling.
5. When the switch is turned to the TIMER position, The lights will now stay ON for 6 hours and then turn OFF automatically for 18 hours. The product will repeat the same routine in loop every day until you turn it off.