HAUTE DECOR

7.5’ Pre-lit Queensbury Fir
2,200 ct. 8-Function Cluster LED Lights
Item # DCCT7508



IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY.

PARTS LIST

- **1 EA. TREE STAND (WITH 1 SCREW)**
- **1 EA. TREE SECTION A (BOTTOM)**
- **1 EA. TREE SECTION B (MIDDLE)**
- **1 EA. TREE SECTION C (TOP)**

ASSEMBLY

CAREFULLY REMOVE THE CONTENTS FROM THE CARTON AND KEEP THE CARTON FOR FUTURE STORAGE. BE SURE TO UNTANGLE ANY WIRES THAT MAY BE TANGLED WITH OTHER ITEMS. PLEASE DO NOT FORCIBLY REMOVE ANY CONTENTS.

Step 1: Locate the **TREE STAND**. Rotate the legs until the stand forms an "X" shape (**see Fig. 1**). Turn the stand's screw to the right a couple of times to lock the legs into place but leave space inside the hub for the tree pole to slide down.



Fig. 1

Place the stand where you are going to set up the tree. ⚠ IMPORTANT: DO NOT PLACE THE TREE WHERE IT IS LIKELY TO WOBBLE DUE TO UNEVEN FLOORS OR THICK CARPETING. PLACE THE TREE ON A FIRM, LEVEL SURFACE.

Step 2: Find **TREE SECTION A**, tagged with the letter "A". Remove the green pole cap (**see Fig. 2**) that is covering the bottom of the pole. It is a protective cover only and can be kept for storage if desired.



Fig. 2

Insert TREE SECTION A into the TREE STAND (**see Fig. A**). Do not force the pole. It will slide down to its correct position. Make sure the pole is seated firmly in the stand. Finish turning the stand's screw to the right until it touches the pole. If TREE SECTION A is not sitting straight, then simply loosen the screw, adjust the tree pole, and retighten the screw.

Allow the branches to fall into place. The branches are connected to the tree pole by metal hinges (**see Fig. 3). NOTE**: SOME BRANCHES MAY CATCH ON ONE ANOTHER. IF THAT OCCURS, SLOWLY PRESS DOWN ON EACH BRANCH UNTIL IT FALLS INTO PLACE.



Fig. 3

Step 3: Locate **TREE SECTION B**, tagged with the letter "B". Remove the green pole cap (**see Fig. 2**) from the bottom of the pole. INSERT TREE SECTION B into TREE SECTION A (**see Fig. B**). Make sure the section is seated securely. Allow the branches to fall into place.

NOTE: THE TOP, INNER PART OF THE POLE TO TREE SECTION B HAS A GREEN POLE ADAPTER INSIDE. THIS POLE ADAPTER IS NOT TO BE REMOVED. TREE SECTION C HAS A GREEN STEM COMING OFF THE BOTTOM OF ITS POLE, WHICH FITS SNUGGLY INTO THIS ADAPTER AND GIVES STABILITY TO YOUR TREETOP.

Step 4: Locate **TREE SECTION C**, tagged with the letter "C". Insert TREE SECTION C into TREE SECTION B (**see Fig. C**). Make sure the section is seated securely.

⚠ **CAUTION: TWO PEOPLE MAY BE NEEDED TO BALANCE AND ASSEMBLE UPPER TREE SECTION. PLEASE USE A LADDER, IF NEEDED, AND FOLLOW ALL LADDER SAFETY INSTRUCTIONS.**

TIP: THIS TREE HAS MEMORY WIRE SO ONLY MINIMAL SHAPING IS REQUIRED. IF THE TREE HAS BEEN ASSEMBLED AND DOES NOT LOOK AS FULL AS THE PICTURE, YOU CAN INCREASE THE OVERALL FULLNESS BY SHAPING EACH BRANCH. THE BRANCHES HAVE BEEN CONDENSED TO FIT INTO THE BOX AND CAN BE EASILY RESHAPED TO THEIR ORIGINAL FULLNESS BY BENDING AND SEPARATING EACH OF THE BRANCHES IN A MORE REALISTIC MANNER. SEE SECTION ON SHAPING.



Fig. A



Fig. B



Fig. C

Step 5: Your tree is pre-lit with 2,200 8-Function Cluster LED lights. Following are the lighting steps. **SEE LIGHTING DIAGRAM (FIG. 4) FOR A VISUAL OF THE LIGHTING SCHEMATIC.**

5.1 In TREE SECTION C, locate the light set plug (labeled with a number 2) and connect it to the light set plug (labeled with a number 2) found in TREE SECTION B.

> ⚠ **IMPORTANT: DO NOT REMOVE THE NUMBERED LABELS 1 ON YOUR LIGHT SETS. THEY WILL HELP YOU TO EASILY FIND THE PLUGS AND CONNECT THE FOLLOWING YEAR.**

5.2 In TREE SECTION B, locate the light set plug (labeled with a number 1) and connect it to the light set plug (labeled with a number 1) found in TREE SECTION A.

5.3 In TREE SECTION A, there is a Power Adapter to guide down through the tree to the floor. Insert it into a grounded 120V wall outlet in your home or into a U.L. approved power strip (not included).

5.4 Tap the Foot Pedal (see **Fig. 5**) to turn the lights on/off and to switch between light functions.
See **Fig. 6** for a list of the functions.

> **FIRST USE: YOUR TREE IS SET TO A DEMO MODE TO DISPLAY ALL THE AVAILABLE FUNCTIONS. TO EXIT THE MODE, HOLD THE FOOT PEDAL DOWN FOR 5 SECONDS. A BLUE LIGHT WILL ALSO FLASH INSIDE THE FOOT PEDAL TO SIGNAL THE MODE HAS ENDED. NOTE: IF THE FOOT PEDAL IS HELD DOWN FOR 5 SECONDS AGAIN, IT WILL RE-ENTER THE DEMO MODE.**



LIGHTING DIAGRAM (Fig. 4)

IF YOU HAVE ANY LIGHTS NOT WORKING, THEN CONFIRM ALL PLUG CONNECTIONS ARE SECURE AND VISIT THE SECTION ON TROUBLESHOOTING FOR LIGHTS.



Fig. 5

LIGHT FUNCTIONS:

1. **Steady WARM WHITE**
2. **Steady MULTICOLOR**
3. **Alternate WHITE & MULTICOLOR**
4. **Twinkle WARM WHITE**
5. **Twinkle MULTICOLOR**
6. **Slow Fade WARM WHITE**
7. **Slow Fade MULTICOLOR**
8. **Light Display (Cycles Above Functions)**
9. **OFF**

Fig. 6

SHAPING

THIS TREE HAS MEMORY WIRE, BUT MINIMAL SHAPING MAY STILL BE NEEDED BECAUSE THE TREE HAS BEEN INSIDE A BOX.

1. Turn on the lights as you are shaping the tree.
2. Reference the tree image on the cover of this instruction manual. It will help guide you on how the tree should look properly shaped.
3. Shape by section and layer, starting at the bottom of the tree and working your way up to ensure coverage of the whole tree.
4. On each branch, begin with the tips closest to the pole and work your way to the end of the branch.
5. The tips should be shaped up and to the sides, resembling a peacock's fanned tail. Offset the tip from the tip before hiding the tree's pole and filling spaces. Continue spreading the tips until they resemble that of a real tree.
6. Due to the height of the tree, it is recommended to shape the top section before placing it on the tree to avoid shaping from a chair or ladder. The bottom two rows are hinged and will fall into place. The remaining upper branches are not hinged so gently pull the branches down and angle them with the rest of the tree.
7. After shaping the whole tree, step back and take an overall look. Shift branches to fill any gaps. Your tree is now ready to decorate and enjoy!

CLEANING & CARE

AS YOU WILL BE USING THE TREE EVERY YEAR, THE FOLLOWING ARE TIPS TO KEEP IT IN GOOD CONDITION AND CLEAN:

- Dust gently using a soft cloth or fabric duster.
- Do NOT use any chemicals or solvents to clean.
- Handle the light sets gently. Do NOT pull or tug light sets as this may inadvertently loosen the bulb.
- Follow all the Storage and Safety Instructions.

STORAGE

PROPER TREE HANDLING AND STORAGE WILL HELP YOU GET THE MOST OUT OF YOUR TREE FOR MANY YEARS TO COME.

1. Remove any ornaments and decorations added by you that did not come with the tree.
2. Unplug the tree from the power source in your home and disconnect the light set plug between each tree section.
3. Starting with the top, separate each tree section and stand gently, being sure not to roughly handle as it could cause damage to the parts. TIP: If there is difficulty separating the tree sections, apply a small amount of lubricant where the poles join.
4. Compress each tree section by turning it upside down and squeezing the branches together so that it will fit more easily into the storage box or container. You can also tie a ribbon or cord around the sections to secure the branches closer together for storage.
5. Return the tree stand to a folded position by turning the screw to the left then rotating the legs.
6. Place all the parts gently back into the storage box. The box will help prevent the tree from being damaged should it get bumped in your garage, basement, or other storage location. Tape the box shut to keep out any dust or insects. When packing up the tree, please ensure that there is no stress or strain to the tree.
7. Be sure to store the tree in a cool, dry area free of water and moisture to prevent mold and mildew from accumulating and a musty odor from developing. Exposing your tree to excessive heat or humidity may damage your tree. DO NOT STORE THE TREE IN A DAMP AREA OR IN AN AREA WHERE THE TEMPERATURE EXCEEDS 100ºF. STORE THE CARTON FLAT AND NOT UPRIGHT ON ITS SHORT END.

TROUBLESHOOTING FOR LIGHTS

IF YOUR LIGHTS ARE NOT WORKING, THE FOLLOWING ARE TROUBLESHOOTING STEPS TO TRY:

1. Check the tree's power adapter for proper connection to a working wall outlet.
2. Step or press the foot pedal on/off.
3. Verify the power to your wall outlet in your home is working properly.
4. Check the light set plugs within the tree for proper positioning and tight connection. Reference the **LIGHTING DIAGRAM (FIG. 4)**. Plugs are keyed to fit one direction only with the flat section of the female plug matching up to the flat section of the male plug.



5. The lights have two settings which are similar, LIGHT DISPLAY and DEMO MODE. Both settings will cycle through the different light functions automatically. Pressing the foot pedal once will exit LIGHT DISPLAY and turn the tree off. If pressing the foot pedal once does not turn the tree off, then the tree is in DEMO MODE. To exit DEMO MODE, hold the foot pedal down for 5 seconds. A blue light inside the foot pedal will also flash to signal the mode has ended.

NOTE: LED bulbs are permanent and cannot be removed from the light sets.

IMPORTANT SAFETY

THIS TREE IS SAFE FOR INDOOR USE ONLY.

PLEASE READ AND FOLLOW ALL THE INSTRUCTIONS AND WARNING TAGS THAT ARE ON THE TREE AND PROVIDED WITH THE TREE.

SAVE THESE INSTRUCTIONS – THIS MANUAL CONTAINS IMPORTANT SAFETY AND OPERATING INSTRUCTIONS.

WHEN USING ELECTRICAL PRODUCTS, BASIC PRECAUTIONS SHOULD ALWAYS BE PRACTICED INCLUDING THE FOLLOWING:

1. WARNING: Risk of Fire. Electrical installation in homes involves special wiring methods to run wiring through a building structure. Consult a qualified electrician. Installation work and electrical wiring must be done by qualified person(s) in accordance with all applicable codes and standards, including fire-rated construction. Reference the National Electrical Code, NFPA 70, specifically for the installation of wiring and clearances from power and lighting conductors.
2. CAUTION: This is an electrical product - not a toy! To avoid the risk of fire, burns, personal injury and electric shock, the tree should not be played with or placed where small children can reach it.
3. Do not use an extension cord.
4. Do not install or use it within ten feet of a pool.
5. Do not use it in the bathroom.

6. Do not use this product if the power adapter or light sets are damaged. Always inspect light sets and electrical cords for signs of damage or wear.
7. Be careful not to overload electrical circuits by plugging too many lights and decorations into a single outlet. Overloaded outlets can overheat and cause a fire.
8. This seasonal use product is not intended for permanent installation or use.
9. This product is not intended for commercial purposes.
10. Do not secure the wiring of this product with staples or nails.
11. Do not alter the construction of the wiring in any way.
12. Unplug the product when leaving the house, retiring for the night, or if left unattended.
13. Do not use this product for anything other than its intended use.
14. Do not hang ornaments or other objects from the cord, wire, or light string.
15. Do not close doors or windows on the product or its light set cords as this may damage the wire insulation.
16. Do not cover the tree with cloth, paper, or any material not part of the tree when in use.
17. Do not mount or support strings in a manner that can cut or damage the wire insulation.
18. Do not mount or place near gas or electric heaters, fireplaces, candles, or other similar sources of heat.
19. This product should not be used with a voltage converter.

THE FOLLOWING SAFETY INSTRUCTIONS APPLY TO THE POWER ADAPTER PART ONLY.
ONLY THE POWER ADAPTER PART IS RATED FOR INDOOR AND OUTDOOR USE.
ALL OTHER PARTS ARE NOT MEANT FOR OUTDOOR USE.

1. WARNING: Risk of Electric Shock. When used outdoors, install only to a covered Class A GFCI protected receptacle that is weatherproof with the power unit connected to the receptacle. If you do not have this receptacle, contact a qualified electrician for proper installation. Ensure that the power unit and cord do not interfere with completely closing the receptacle cover.
2. WARNING: Not to use with receptacles that are weatherproof, unless it is a covered receptacle (attachment plug cap not inserted, and receptacle cover closed).
3. WARNING: Risk of Electric Shock. Mount the unit at a height greater than one foot from the ground surface.

FCC COMPLIANCE STATEMENT

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CANADA ISED COMPLIANCE STATEMENT

This device complies with CAN ICES-005 (B) / NMB-005 (B). Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and
(2) this device must accept any interference, including interference that may cause undesired operation of the device.

CUSTOMER SERVICE



THANK YOU FOR YOUR PURCHASE!
Comments or questions?
Contact us at 1-877-359-0115
customerservice@haute-decor.com
Haute Decor
PO Box 1594
Allen, TX 75013

©2024 Haute Decor

Made in China