210*140MM
23/11/08

SNAILAR

SNAILAR INC
1226 NORTH KING ST.,WILMINGTON DE 19801
E-mail: support@snailar.com
Website: www.snailar.com

Intertek

SNAILAR

Model No.:ABS07-W
ABS07-G
ABS07-F
ABS07-S

USER MANUAL

Sandwich Maker

Please read this instruction manual carefully before use.

KNOW THE SANDWICH MAKER

1. Lacquered phenolic Exterior
2. Indicator Lights (Red)
3. Indicator Lights (Green)
4.Clip To Fasten Handles
5. Non-Stick Coated Toasting Plates
6. Handles

GENERAL SAFETY INSTRUCTIONS

• Please read this Instruction Manual carefully before use.
• Keep these instructions; the guarantee certificate; the sales receipt; and the gift box with the inner packaging if possible.
• Remove the mains plug from the supply whenever the SANDWICH MAKER is not in use.
• Under no circumstances must the SANDWICH MAKER be placed in water or other liquids.
• Test the SANDWICH MAKER and the cable regularly for damage. If there any kind of damage, the SANDWICH MAKER should not be used.
• In case of repairs, replacement of cord or plug, or adjustment, please consult a qualified technician or take the SANDWICH MAKER to an authorized service facility.
• Keep these instructions in a safe place for future reference.
• The appliance is not intended for use by persons(including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge unless they have

been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
• In order to avoid a hazard due to inadvertent resetting of the thermal cutout, this appliance must not be supplied through an external switching device, such as a timer, or connected to a circuit that is regularly switched on and off by the utility.
• For indoor household use only.

USING THE SANDWICH MAKER

• Before using the SANDWICH MAKER for the first time, peel off any adhesive labels.
• Pour a teaspoon of vegetable oil onto the Non-Stick Coated Toasting Plates. Spread over using an absorbent kitchen towel and wipe off any excess oil.

1. CONNECTING TO THE MAINS SUPPLY / PREHEATING

• Connect the mains plug to the supply, the Red and Green Indicator Lights illuminates immediately. As soon as the Green Indicator Light go off (after about 4-5 minutes), the preheating time is complete and toasting can commence.
• The SANDWICH MAKER may give off a slight odor and smoky haze when used for the first time. This is normal.

2. TOASTING

• Prepare the Sandwich as directed in the recipe and place the bread, buttered side down, on The Bottom Non-Stick Toasting Cooking Plate for Sandwich making.
• Lower the Top Non-Stick Coated Toasting Plate, and use the Clip to fasten the Handles.
• Toast for approx. 3 to 6 minutes or until golden brown.
• Adjust the time to suit an individual taste.
• It is normal for the Indicator Lights to switch on and off during use.

HINTS FOR GOOD RESULTS

• For best results, use medium sliced bread with or without crusts. Remember to increase the cooking time slightly for thick-sliced bread and to reduce slightly for the thinly sliced bread.
• Brown bread can also be used but the toasting time may differ.
• Toast sliced bread that fits the SANDWICH MAKER or cut the bread to fit. (Any left over pieces can be made into bread crumbs).
• Use only butter or ordinary margarine when preparing toasted sandwiches. Synthetic or low fat spreads are unsuitable as they overheat at a lower temperature, forming dark brown deposits that can cause the toasted sandwich to stick to the Non-Stick Coated Toasting Plates.
• Unlike conventional sandwiches, the bread is buttered on the outside. Take care not to use too much filling otherwise it will leak from the toasted sandwiches.
• Avoid using delicate salad fillings which will soften such as lettuce and cucumber when toasted. Salad items such as tomatoes and onions give good results..

CARE AND CLEANING

1. Remove the mains plug from the mains supply.
NOTE: NEVER IMMERSE THE SANDWICH MAKER IN WATER.
Allow cooling with the Top Non-Stick Coated Toasting Plate open.
2. Wipe the Non-Stick Coated Toasting Plates with a cloth rinsed in hot water and washing-up liquid.
3. Never use hard abrasive powders, wire wool or hard abrasive scourers. Sponge scourers sold for use on non-stick pans, called non-stick sponge scourers, can safely be used.
4. Wipe dry with a clean cloth and an absorbent kitchen towel.