Assembly Instructions & User's Manual for Hanging Tent

THIS ASSEMBLY MANUAL CONTAINS IMPORTANT SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

TOOLS REQUIRED

- SOCKET WRENCH
- 3 AA BATTERIES
- 13MM SOCKET
- PENCIL & RULER
- DRILL
- HAMMER

- 330 LBS CAPACITY (COMBINED)
- 2 PERSON ASSEMBLY
- APPROXIMATELY 60 MIN ASSEMBLY

PARTS FOR STAND

- A1 x 2PCS
- B1 x 2PCS
- C1 x 2PCS
- D1 x 2PCS
- E1 x 1PC
- F1 x 8PCS
- G1 x 1PC
- H1 x 1PC
- I1 x 1PC

PARTS FOR TENT

- 1 M8 x 60mm SLEEVE ANCHOR — 4 PCS
- 2 MOUNT — 1 PC
- 3 ROPE — 1 PC
- 4 CARABINER — 2 PCS
- A TENT — 1 PC
- B TOP FRAME — 3 PCS
- C BOTTOM FRAME — 4 PCS
- D CUSHION — 1 PC
- E STRING LIGHTS — 1 PC
- F INFLATOR — 1 PC
- G 2 LAYER TOP — 1 PC

Attention!

Please remove the grey cap before assembling.



Each C1/D1/E1 bar comes with grey protection caps for transportation. Please remove the caps before assembling.

Protection caps may be damaged during transportation, which is a normal phenomenon and not a quality issue.

PRODUCT ASSEMBLY





1 Place the base piece(Part E1) on a level surface.

2 Insert the four pieces(Part C1 & Part D1) into Part E1, secure them with screw Part F1.

3 Connecting Part B1 and Part C1 by screw Part F1.

4 Insert Part A1 into Part B1, secure them with screw Part F1.

5 Secure two Part A1 tubes with connector Part H1.

6 Attach Part I1 into top of stand, hang Part G1 to the Part I1 chain.

Attention: This stand is designed exclusively for use with the tent sold together and is not recommended for use with other products.

At the beginning of use, please do the following:

- Before using, make sure base is secure and located on a flat level surface. Inspect overall condition before using this product.
- Check all moving parts including the seat, frame, and hardware for wear, rust, or deterioration. Replace as needed. Check all metal parts for rust. If found, sand and repaint, using a non-lead-based paint.
- It is recommended to take down and store your hanging tent to extend the life of the product.
- Check all nuts and bolts for tightness and tighten when required.
- Remove all parts and hardware from the box. Place all items on a carpeted or scratch-free work surface, as this will avoid damaging parts during assembly.
- To avoid accidentally discarding small components or hardware, do not dispose of any packaging or contents of the shipping carton until assembly is complete.
- Do not fully tighten all fasteners / screws until all parts are in place.

PRODUCT ASSEMBLY

1 Slide three part B top frames into the designated sleeves inside the part A tent. Attach the top frames to one another.



2 Attach four part C bottom frames. Secure the bottom frame to the bottom of the tent with the attached adhesive strips.

PRODUCT ASSEMBLY

3 Place the cushion D in the zippered compartment at the bottom of the tent.



4 Install 3 AA batteries in the part E string lights. Place the battery box in the pocket, then route the string lights through the loops on the top of the tent.

Use switch to cycle between OFF, ON.



MOUNTING SWING

1 Line up the part 2 mount and use a pencil to mark the desired mounting location.



2 Drill four holes at the mounting location.
NOTE: Drill approximately a ¼" deeper than the length of the sleeve anchor.



MOUNTING SWING

3 Insert four part 1 sleeve anchors into the holes. Use a hammer if necessary.
Remove the nuts/washers from the sleeve anchors.



4 Place the mount, then tighten the nuts to secure the mount.



MOUNTING SWING

5 Use the part 4 carabiners and part 3 rope to hang the tent swing from the mount.
NOTE: The swing can also be installed on a stand, tree branch, beam, etc.



INSTALLATION TIPS

- Make sure overhead structure can support a minimum of 330 lbs. If hanging from a tree, diameter of tree limb should be 10 inches.
- Have adults test the overhead structure by pulling down or sitting in the swing.
- Do not install over concrete, asphalt, or hard ground.
- Swing should have a fall zone surrounding of the swing.
  - Fall zone should extend a minimum of 18 inches on each side and twice the swing height on the front/back.
- Place soft padding around the swing if ground is too hard.
- Do not use in a place with excessive sunlight. In warm weather, make sure that the tent swing surface is not too hot.
- Swing height should be 12 to 18 inches above the ground.
- Swing must have at least 2M of overhead and side clearance from any structure or obstruction such as a fence, garage, house, branches, wires, etc.
- Install in an area clear of wires, walls, structures, furniture, etc.

CARE AND MAINTENANCE

- Reconfirm that all nuts, bolts, and screws are tight and secure.
- Grease hardware and hanging points regularly.
- Check hardware and hanging points for rust which could affect their strength. Replace if necessary.
- Check seat, air cushion, and tent for excessive wear and tear.
- Check ropes for fraying, wear, or breakage. Replace if necessary.
- Do not leave the tent swing outdoors for an extended period of time.
- In winter season, it is recommended that the tent swing is stored indoors.
- To clean, wipe down with a damp cloth.
- Store in a dry place away from direct sunlight.
- Cover or store in a bag if unused for an extended period of time.

⚠ NOTICE

Please retain these instructions for future reference.

- Adult assembly and installation is required.
- This swing is for household, indoor/outdoor use only.
- Only use with adult supervision. Do not allow children to play alone.
- A maximum of two children are allowed on the swing at a time.
- Do not stand on or use any part of this item as a step ladder.
- Firmly secure all bolts, screws and knobs before use.
- Reconfirm that all bolts, screws, and knobs are secure every 90 days.
- This item is not intended for use by persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the item by a person responsible for their safety.
- If any parts are missing, broken, damaged, or worn, stop using this product until repairs are made and/or factory replacement parts are installed.
- Do not use this item in a way inconsistent with the manufacturer's instructions as this could void the product warranty.

AGE RANGE: 3 years old and up

USER WARNINGS

- Before use, make sure the swing is in good condition and that the hardware/hanging points are secure.
- Do not use swing if equipment is wet.
- Do not swing beyond a 45° angle.
- Do not place anything underneath the swing that could hinder or obstruct the swinging motion.
- Do not attach items to the swing (jump ropes, clotheslines, cables, chains, etc.) as this could be strangulation hazard.
- User must dress appropriately to use swing. Do not wear loose clothing or clothing with cords and drawstrings.
- Remove shoes when using swing.
- Do not jump on the swing or jump into the swing. Step onto the swing carefully.
- Do not jump off the swing.
- Do not walk or stand in the proximity of a moving swing.
- Do not push an empty swing as it may hit a person and cause injury.
- Only sit in the swing; do not stand.
- During use, stay in the center of the swing.
- Maintain control of the swing at all times.
- Do not use if any part of the swing is broken or loose.

0-3

⚠ WARNING:

Adult assembly and supervision required.
This product should be unpacked and assembled by an adult,including site and tree selection.
In unassembled state, it contains potentially hazardous small objects, please keep out of children's reach.

Warnings:
AGE RANGE: 3Y+
The product is suitable for individuals weighing up to 150kgs.
This swing is for household, indoor/outdoor use only.
Warning! Only for domestic use.

Ningbo Dory Outdoors Co.,Ltd
Add: 4th Fl, Yingchun Road, Haishu District, Ningbo, China
Made in China

⚠ WARNING

Manufacturer and seller expressly disclaim any and all liability for personal injury, property damage or loss, whether direct, indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.

折页

展开：888*210mm