

ASSEMBLY INSTRUCTION

A		1 pc
B		1 pc
C		1 pc
D		1 pc
E		1 pc
Packing Hardware		

Step 1: Attach the back panel (B) to arm (A). Attach side rail (D) to arm (A) by pushing the bracket down to fit it. Tighten with Allen Key (1).

BACK VIEW

Step 2: Attach middle panel (E) to arm (A) by pushing the bracket down to fit it. Tighten with Allen Key (1).

1		1 pc
	M5 x 70 mm	
2		1 pc
	M5 x 65 mm	
3		28 pcs
	CSK M4 x 32mm	
4		12 pcs
	JCBB M8 X 20	
5		4 pcs
	JCBC M6 X 50	
6		4 pcs
	FLAT WASHER	

Step 3: Tighten the slats with CSK screw (3). The distance of the slats should be sufficient to obtain desirable bed stability.

C