

Assembly instructions for privacy screens



Step 1.- Locate top banner of privacy screens (3) and screws (12).

Step 2.- Position the top banners on the each panel of the privacy screen using the numbers printed on each part.

Step 3.- Using a power drill or screwdriver, drill in the screws to pin up the banners to each panel.

Note: align using the numbers printed on each part.