



FREESTANDING BATH TUB INSTALLATION INSTRUCTIONS

GENERAL GUIDELINES:

- 1) PREMIER COPPER PRODUCTS RECOMMENDS USING A PROFESSIONAL INSTALLER TO INSTALL OUR PRODUCTS.
- 2) BEFORE INSTALLATION, UNPACK AND INSPECT YOUR TUB FOR DAMAGES. IF ANY DAMAGE IS FOUND, PLEASE CONTACT 877-251-4486.
- 3) ENSURE THAT THE FLOOR AND SURROUNDING AREA PROVIDES ADEQUATE SUPPORT AND SPACE FOR YOUR TUB.
- 4) DETERMINE WATER LINE LOCATIONS AND PLUMBING CONNECTIONS PRIOR TO INSTALLATION. BATH TUB FAUCET OR FILLER MAY NEED TO BE ASSEMBLED PRIOR TO INSTALLATION.
- 5) PLEASE REVIEW THE CARE INSTRUCTIONS THAT CAME WITH YOUR TUB. ABRASIVE CHEMICALS SHOULD NEVER BE USED ON OUR PRODUCTS AS IT WILL STRIP THE PATINA OFF THE TUB. USE ONLY MILD, NON-ANTIBACTERIAL SOAP AND WATER WITH A SOFT CLOTH FOR CLEANING.

INSTALLATION:

- 1) DRAIN TYPE AND CONNECTION SHOULD BE DETERMINED PRIOR TO INSTALLATION.
- 2) WE RECOMMEND USING OUR COLOR MATCHED INSTALLATION SILICONE (MODEL: C900-ORB) FOR THE DRAIN INSTALLATION. IF YOU DO NOT HAVE THIS, YOU CAN USE CLEAR 100% SILICONE (NON-WATER BASED) PURCHASED AT ANY HARDWARE STORE. USING PLUMBERS PUTTY WILL CREATE A "BULLS EYE" EFFECT AROUND YOUR DARK DRAIN DUE TO THE WHITE COLOR OF THE PUTTY.
- 3) PLACE YOUR TUB IN THE DESIRED LOCATION. ENSURE THAT THE FLOOR IS LEVEL AND YOUR TUB IS SECURE.
- 4) INSTALL DRAIN ACCORDING TO THE MANUFACTURER'S INSTRUCTIONS.
- 5) INSTALL FAUCET ACCORDING TO THE MANUFACTURER'S INSTRUCTIONS.
- 6) ONCE INSTALLATION IS COMPLETE AND SILICONE HAS DRIED THOROUGHLY, FILL UP THE TUB TO CHECK FOR ANY LEAKS.

