

**Fin
Coat Hook**
Brendon Farrell



Hanging Template Instructions

1. Attach the template to the wall in the desired location using low tack masking tape.
2. Use a spirit level along the level line, adjust until straight. If using multiple coat hooks, place the templates joined side to side.
3. Drill holes where marked on the template using a suitable drill bit for your wall plugs (not supplied).
4. Remove template from the wall and insert the wall plugs (not supplied).
5. Insert and affix screws into the wall plugs, leaving enough protruding to hook the coat hook onto.

