

# TWO TIER BOOT TRAY

Thank you for purchasing this Two Tier Boot Tray. The product is supplied with all of the required fixings. Your Two Tier Boot Tray has the following contents -

Qty	Item Description
2	Plastic Boot Tray Mouldings
4	Aluminium Tube Sections
8	Plastic Tube End Bungs
8	Stainless Steel Self Tapping Screws
4	Self-Adhesive Rubber Floor Buffers

## ASSEMBLY INSTRUCTIONS

In order to assemble this Two Tier Boot Tray, you will require a screwdriver and a hammer.

### Step 1

Firstly, position a Plastic Tube End Bung into the end of each Aluminium Tube Section. The recommended method is to push in the End Bung by hand as far as possible. This should ensure that the End Bung is held in position. Then, using a hammer, hold the tube upright, ensuring that the End Bung at the bottom of the tube is in contact with a hard surface such as the floor or a workbench. Hammer the End Bung in the top of the tube into place. Once complete, turn the tube round and hammer the other End Bung into place.

### Step 2

Position each Tube Section into the inside corner of one of the trays which will become the lower tray. Align the hole of the exposed End Bung with the hole in the tray. From the underside of the tray, push one of the Stainless Steel Self Tapping Screws through the hole in the tray and screw into place. We suggest that the screws are not full tightened at this stage. Carry out this operation so that all of the tubes are now connected to the lower tray.

### Step 3

Position the remaining tray which is now the upper tray on top of the exposed tube ends. Align the holes of the tray with the holes of each exposed End Bung and using the remaining Stainless Steel Self Tapping Screws, secure the upper tray into place, by tightening all the screws.

### Step 4

Position a Self-Adhesive Rubber Floor Buffer in all four corners of the underside of the bottom tray. This ensures that the exposed screw head is not in direct contact with the floor surface. The Self-Adhesive Rubber Floor Buffers should be positioned as close as possible to each screw head on the raised ridge section of each tray. Your Two Tier Boot Tray is now ready for use.