

USER MANUAL

1. Use a screwdriver to tighten and secure the base to the column.



Special note:

For model S008, the base installation screw holes are countersunk 10mm. When installing, tighten the screws all the way until they are secure. Refer to the right image for illustration.

Countersunk Hole



广州市德顺音响有限公司
deshunle.1688.com



往下看有惊喜

2. After securing the base, select some dry sand (moist sand can corrode the column over time) and pour it into the top of the column, filling it to about seven or eight tenths full. This not only enhances the bass effect but also increases the stability of the column.

Special Note: Our store does not offer sand.



广州市德顺音响有限公司

Look down for surprises

deshunle.1688.com

3. After filling with sand, use screws and a screwdriver to tighten and secure the tray to the column.



往下看有惊喜



Accessories Usage:

Non-slip Pad: Remove a layer of film from the base and then stick the non-slip pad on the four corners of the tray (refer to the right image for illustration).

