

# 1" DRAPERY ROD INSTALLATION INSTRUCTIONS - 18-36" ROD SET

Care Instructions: Clean with a soft cloth. Do not use abrasive cleaning agents, solvents or polishes.

**SET INCLUDES:**

(A) (B) (C) (D) (E) (F)

X4 X4 X2 X1 X1 X1

Extends 18-36"  
X1

Note: Finial (D w/ smaller post) fits to the smaller diam. rod - Finial (E w/ larger post) fits to the larger diam. rod.

**YOU WILL NEED:**

1/4" dia.

**1**

Extends 18-36"

Before installation, measure windows to determine appropriate drapery rod length.

**2**

Use bracket (C) as a guide to mark location for mounting screws (A).

**3**

Drywall

Drill pilot holes into wall with 1/4" drill bit (not included). Insert wall anchors (B) and attach bracket (C) using mounting screws (A). Wall anchors may not be necessary if drilling into studs.

**4**

Repeat steps 2-3 for additional bracket. Use level if necessary.

**5**

Extend telescoping rod (E) slightly.

**6**

Place drapery panels (not included) onto drapery rod and extend to desired length. Hang rod on brackets. Insert finials (D & E) into ends of rod and tighten set screws on brackets (C).