

INSTRUCTIONS:

1. Position the slide bar on the tub wall in desired location and mark the placement on the wall.
2. Mark the location of the two mounting holes, positioned 24" apart.
3. Using a 7/32" drill bit (use a masonry bit for tile), drill both holes in the tub wall and insert the included anchors.
4. Ensure that the slide bracket and soap dish are in place on the slide bar before proceeding.
5. Remove the end cap from the slide bar attachment supports and place the top support in place on the bar. Insert a screw through the support and bar and screw it into the wall anchor.
6. Place the other support onto the bar and insert a screw through the support and bar and screw it into the wall anchor.
7. Replace both support end caps.
8. Remove existing shower head if applicable. Apply thread sealant tape to shower arm, diverter, or drop elbow threads depending on your application.
9. Insert washer between one end of the hose and the appropriate water supply connection. Hand tighten plus a quarter turn with a wrench. Do not overtighten.
10. Insert remaining washer between showerhead and hose. Thread new showerhead onto hose and hand tighten.
11. Slide hose and showerhead through bracket and seat the showerhead into the diverter bracket.

To adjust the height of the shower head simply press the gray button and move the slide bracket up or down. The slide bracket can also adjust the angle of the shower head by rotating forward or backward.

Tip: Use cloth between wrench and nut to protect finish

Note: Bar is not intended to support weight. Do not use this bar as a grab bar, accident and/or injury may occur.