

Poultry Feeder and Waterer assembly instructions.

The Waterer can be mounted several ways on just about any material. If you are mounting on the outside of a chicken coop you will need a hole approximately 4" x 4" for the feeder opening 10"-12" above the ground (breast height) depending on the breed of chickens you are feeding.

If you are mounting the waterer on the outside of a chicken coop you will need a hole approximately 2" x 2" for the water valve 8"-10" above the ground (bottom of breast height) depending on the breed of chickens that you are watering.

See picture on "How To Use" side of box



Outside Mounting

1. Cut holes in the desired location on cage. Make sure that the feeder A-frame and water valve moves freely in and out of the newly made holes.
2. Drill in mounting brackets evenly aligned and centered vertically with holes you just made.
3. Line up the hanging clips with the mounted brackets and drill into feeder/waterer tube so that both hanging clips latch into the mounting brackets evenly.



Wall Mount

1. Screw hanging clips into feeder/waterer desired location.
2. Screw Mounting Brackets to wall at desired height. Align hanging clips with brackets and attach to feeder/waterer.

HOW DO I GET MY BIRDS TO START EATING OUT OF THE POULTRY FEEDER?

There is no training involved in getting your birds started with the new High End Poultry feeder. Simply fill the tube and mount your feeder. Once mounted, FILL THE FRONT OF THE FEEDER COMPLETELY SO THAT YOUR BIRDS CAN SEE THE FOOD. That's it. That's all there is to do to get them started. They will now eat from the feeder without having to add food to the front of the feeder again.