



ASSEMBLY INSTRUCTIONS

Chair Assembly Precaution:

Gently tap the dowel with a hammer until it is fully seated at the bottom of the hole, leaving approximately 1/4" exposed. Make sure the dowel is completely inserted, as an improperly seated dowel may break through the chair seat when the seat is installed.

