

Crystal Cabinet Knobs

A

1) Hold the knob in a position that is easy to reach, and aesthetically pleasing. This is commonly in the location shown in the drawing to the right for upper cabinets.

2) Mark the location with a pen or pencil.



**KNOBS ALWAYS MOUNT
OPPOSITE THE HINGES**

B

1) Use a 1/4" drill bit, and drill through the cabinet door in the marked position.

2) Drill from the outside.

3) Drill all other doors in the same position.

C

1) Mount cabinet knob using the shortest included screw that fits.

2) Tighten the screw by hand. Do not tighten with electric drill/driver.

3) Do not over-tighten.