JAMIE YOUNG co.

FRENCH CLEAT
INSTALLATION INSTRUCTIONS

PLEASE READY ALL INSTRUCITONS PRIOR TO HANGING

The knob included with your mirror is decorative only and is not meant to hold the weight of the mirror. You must use the enclosed French Cleat to hang your mirror.



1. **ATTACHING THE WALL CLEAT**: Measure and mark for the position of the wall cleat on the wall. The wall cleat should be oriented so that the screw holes are on the bottom and the top edge is open and out from the wall. This cleat must be installed as level as possible.
2. Attach the cleat to the wall at your marks using the #8 x 1" screws and plastic wall anchors provided. Small adjustments to level can be made by making use of the slotted screw holes.
3. To hang the mirror, place it flush against the wall so that the bottom edge of the mirror cleat is positioned slightly above the top edge of the wall cleat and the entire mirror is centered on the wall cleat. Let the mirror slide down the wall slowly and evenly until the cleats connect together completely
4. Some side-to-side adjustment can be made by lifting the frame slightly and shifting it to the left or right. Make sure that the frame cleat and the wall cleats are engaged along at least 90% of their length.
5. To remove the mirror from the wall completely, lift the mirror directly upward a couple of inches to disengage the cleats.

SAVE THESE INSTRUCTIONS