

# Easy and convenient installation

## Wall hanging installation method



Install the expansion screw into the wall



Hang the screws into the dovetail hook

## Paste, install, and use



Wipe the wall clean with a dry cloth



Apply a sufficient amount of nail free adhesive evenly on the back



Evenly press the flat surface to expel air



Wait for 72 hours for complete solidification before hanging the mirror

**Special reminder:**

Worn, old, powdery, wallpaper, and other walls are not suitable for use