



**1** Mark holes for mounting.



**2** Punch holes with M8 drill.



**3** Insert expansion bolts into holes



**4** Tighten with screws