

Brightech® Montage Modern Assembly Instructions

1. Remove all parts before assembling and place on a flat surface. To assemble the shade please check page 2 (shade instructions).
2. Screw pole (B) clockwise into base (A) to tighten.
3. Screw pole (C) clockwise into pole (B) to tighten.
4. Screw pole (D) clockwise into pole (C) to tighten.
5. Screw pole (E) clockwise into pole (D) to tighten, screw pole (F) clockwise into pole (E), and pull the remaining slack of the power cord out carefully through the base. **Make sure the lamp stands straight and then use the wrench to tighten the nut at the bottom of base.(see diagram)**
6. Put shade (G) onto the socket and lock the shade into place by screwing on socket ring (H). (Note: socket ring (H) may need to be unscrewed from the socket, before you place shade (G) onto the socket.)

Important Safety Instructions:

This product has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet in only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. DO NOT ALTER THE PLUG.

Max Wattage: 100 watt incandescent or 23 watt CFL equivalent. (Incandescent/CFL not included)
A 9.5 watt LED bulb is included.

Thank you for your purchase of your Brightech lamp. Please contact us via our website or email if you have any issues or concerns.

www.brightechshop.com

wecare@brightechshop.com

