

ASSEMBLY INSTRUCTION

*** Do not fully tighten screws until fully assembled ***

Thank you for purchasing the quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and metal hardware. Compare with all parts list to be sure all parts are present. If any part(s) are missing or damaged, please contact your local furniture dealer. For efficient and speedy service, please indicate the model number and code letter of part(s) needed.

| Part Desc. | | Full/Queen | King |
|------------|-----------------------|------------|--------|
| A | Headboard | 1pc | 1pc |
| B | Foot board | 1pc | 1pc |
| C | Side Rail R/L | 2pairs | 2pairs |
| D | Slat | 4pcs | 4pcs |
| E | Headboard Leg | 2pcs | 2pcs |
| F | Footboard Leg | 2pcs | 2pcs |
| G | Side Rail Support Leg | 2pcs | 2pcs |
| H | Slat Support Leg | 4pcs | 8pcs |

HARDWARE REQUIRED

| Hardware Desc. | | Full/ Queen | King |
|----------------|-----------------------|-------------|-------|
| 1 | M8x40mm Wood Dowel | 2pcs | 2pcs |
| 2 | M8x20mm Bolt Short | 8pcs | 8pcs |
| 3 | M6x25mm Bolt Short | 8pcs | 8pcs |
| 4 | M6x30mm Bolt Middle | 4pcs | 8pcs |
| 5 | M6x50mm Bolt Long | 8pcs | 8pcs |
| 6 | M4x32mm CSK Screw | 8pcs | 8pcs |
| 7 | M5x65mm Hex Wrench | 1pc | 1pc |
| 8 | M4x110mm Hex Wrench | 1pc | 1pc |
| 9 | M6x19mm Flat Washer | 14pcs | 14pcs |
| 10 | M6x13mm Spring Washer | 6pcs | 6pcs |

Attention

***Some number parts listed on the Instruction sheet may not be in parts bag as they may already be assembled.

Carefully check parts and packing materials prior to ordering replacements.

How to assemble:

