

## WALL SCONCE FIXTURE INSTALLATION INSTRUCTIONS

Please read carefully and save these instructions, as you may need them a later date.

### CAUTION

Turn off the main power at the circuit breaker before installing the fixture, in order to prevent possible shock.

### GENERAL

All electrical connections must be in accordance with local and National Electrical Code (N.E.C) standards. If you are unfamiliar with proper electrical wiring connections, obtain the services of a qualified electrician. Remove the fixture and the mounting package from the box and make sure that no parts are missing by referencing the illustrations on the installation instructions.

### ASSEMBLY AND INSTALLATION

- 1, Attach the Cross Bar to the Outlet Box by 2pcs Mounting Screws.
- 2, Make wire connections:
  - Twist together the white wire from the fixture with the white wire from outlet box. Cover with wire connector
  - Twist together the black wire from the fixture with the black wire from outlet box. Cover with wire connector
  - Attach the ground wire to the cross bar with a green ground screw.Carefully tuck wire back into the OUTLET BOX
- 4, Place the Back plate against the Outlet box, secure with the Stem Screw.
- 5, Install bulbs. (Please do not exceed the maximum capacity which is recommended on the sockets).
- 6, Put the glass onto the socket, then use the nut screw it tightly.

INSTALLATION IS NOW COMPLETED.

