

Assembling A KD chair with SoCozi installed

1. Remove the KD wrap from the mechanism back posts.
2. After removing the KD wrap, attach the back to the base of the chair by inserting the back post of the mechanism into the KD brackets on the back. .
3. After connecting the back to the chair make the necessary wire connection.
4. After making the connection, route the hand wand between the chair arm and the back.

