

## Instruction

First, insert the armrest section into the base.



Second, install the screws. If the bed surface can be perforated, you can fix these screws. If you can't make holes, you can press this base with the mattress without screws. Punching holes to install the screws is more solid.

