

Stair Treads

INSTRUCTIONS

Keep your stair mats fresh and clean: For spills or dust, gently dab stains with a damp cloth or vacuum lightly – just press down firmly with your foot as you glide the nozzle to keep adhesive secure (no accidental lift-offs!). When treads need a deeper refresh, toss them in the washing machine – you can slip them into a mesh laundry bag to prevent dust from sticking to the adhesive back.

INSTALLATION STEPS:



Clean Slate Start

Give your step a quick wipe with a damp cloth. Let it go bone-dry—this primes the tread to grip like a steadfast handshake!



Peel & Reveal

Slowly peel off the film (like opening a surprise!). No extra tools or glue needed—the built-in adhesive grips instantly.



Align & Adhere

Set the stair treads perfectly flush with your step's edges. Press center-first, then smooth outward—every corner hugs the wood tightly.



Corner Confidence

Press all 4 corners firmly for 30 seconds (hum your favorite tune!). Now it's secure—protecting people and pets against slips!

- *Set-up Tips: For curved or oddly shaped stairs, grab scissors and snip treads to match your steps — trim slowly along curves for a seamless, gap-free fit.*