

Before you begin!

The DO's

- Apply on finished surfaces only (i.e. primed and painted walls).
- Apply to room temperature surfaces (~68 degrees F, or 20 degrees C).
- Wait at least two weeks before applying to newly painted walls.
- Wash and completely dry your hands before application.
- After applying each sticker, smooth over entire area with pressure, **paying special attention to the edges.**

The DON'Ts

- Do not apply to unfinished surfaces (i.e. bare concrete).
- Do not apply to cold surfaces.
- Do not apply to freshly painted walls (please wait at least two weeks).
- Do not use a squeegee (or anything else besides your hands!) to apply wall stickers.

No-sweat application! Just peel the wall stickers off the sheet and place them on the wall. A word to the wise: remember to keep the backing paper so that you have a place to store your wall stickers when you want to take them off.

Troubleshooting

- What to do if you see air pockets forming during installation: pull back a small section and reapply the wall sticker.
- What to do if air pockets show after installation: poke a hole in the air pocket with a safety pin, then flatten out the sticker.

Handle with Care

- If you need to spot clean, use a dry wallpaper cleaner such as Absorene Antique Wallpaper Cleaner and always test a hidden spot first.
- Please do not use chemical cleaners.

*We are so happy to have
made these wall stickers
especially for you!*

IMPORTANT

Please follow our instructions carefully to ensure easy application and optimal wall adhesion.

Please clean your walls with water and cloth only and allow to completely dry before applying the wall stickers.

If the wall stickers are applied to a dirty or dusty wall, the stickiness of the adhesive will be compromised and the wall stickers may not completely adhere to your wall.

IMPORTANT

simple shapes®

