



Deadbolt Quick-Install Instructions

Step 1:

Insert the bolt into the door. The arrow needs to be pointing upwards, then drill pilot holes for the bolt screws. Attach latch faceplate with provided wood screws.

Step 2:

Attach the lock cylinder side and then rotate the flat metal tailpiece so it is vertical to enter the bolt keeping the tailpiece aligned with the slotted hub as it enters the bolt (the bolt must be extended, not retracted).

NOTE: The Tailpiece length is correct for 1 3/4" thick doors but can be cut for thinner doors.

Step 3:

Slide the interior thumb-turn and trim onto the tailpiece (Keeping the thumb-turn axis vertical) Insert the two, short machine screws into the interior trim, and tighten.

Check the deadbolt operation with thumb-turn (inside) and with the key. If binding occurs, try to slightly loosen either the machine screws, the mounting screws or latchbolt screws.

NOTE: Two different length screws are provided for doors of 1 3/8" (shorter screws) and 1 3/4" (longer screws).

Step 4:

Mount the strike-reinforcement using two, 2-inch long wood screws. Then mount the strike-plate.

Check that the deadbolt extends fully into the strike-plate. Strike-plate and strike-reinforcement (provided).