

Mannington.

Our Restoration Collection® is now easier to install. You can now install using the angle tap over method.

Installation Instructions:

1. Starter row- With the long side tongue facing the starter wall, tap the head seams tight using the tapping block and a hammer.
2. Start the second row with a plank that staggers the starter row by a minimum 12". Click the long side tongue into the previous row's groove.
3. The second plank in the second row will be angle tapped into place. Working tongue into groove, angle the long side tongue into the groove of the previous row and snap it down into place. The short seam tongue should be close to the first plank's short side groove. Then, use the tapping block on the short side groove. The block's notched edge should fit firmly against the laminate and not against the HDF profile. Tap the block with a hammer until the head seam closes completely.
4. Apply a minimum 5/16" spacer on every starting row to ensure the head seam tapping does not move the entire row.
5. Use a pull bar to tap the finishing plank of every row tightly into place.
6. Continue installing tongue in to groove, plank after plank until the job is complete. Always thoroughly check the work after the during and after the install.
7. Remove spacer and install proper trims and moldings.

Continue following the original instructions in regard to- balancing the installation, expansion gap, laminate pad install, staggering, scribing, and plank blending.