

Bifold Doors Assembly

Installation Guide


In case of questions or missing parts, please contact

Dooraftersale@gmail.com



Scan Here For Latest Version
(Barn Doors-BD07)

Assembly Diagram



2-Door Set

4-Door Set




2 PERSON
ASSEMBLY



UP TO 30 MIN.
ASSEMBLY


Notes:

- Wear Safety Goggles
- Dimensions are in inches
Millimeters are shown in brackets
- Fits normal finished opening height of 80 1/2"
- 2-Door and 4-Door Installations below.
For 4-Door Installations, 2 (two) 2-Door
sets will need to be purchased




Tools Needed: Phillips Screwdriver, Pencil, Drill, Measuring Device,
3/16" (5mm) Drill Bit, 3/32" (2mm) Drill Bit (optional for pilot holes).

a




2X Panels

b




1X Fascia

c




1X Fascia Block
(for 4-Door installation)

d




1X Pull

e




1X Upper Pivot

f




1X Lower Jamb Pivot

g




1X Bottom Pivot

h




1X Snagger

i




1X Roller

j



1X Track

k



1X Long Spring
(for 4-Door Installation)

l




1X Long Mount Plate

m




1X Short Mount Plate

n




2X Top/Bottom Hinge

o



1X Center Hinge

p



1X Wrench

q



22X Long Screw

r



8X Short Screw

s




1X Machine Screw (Pull)

Step 1


Prepare Track for Mounting

Insert components as shown in Figure 2 for 4-Doorset or as in Figure 4 for 2-Door set. The Upper Pivot may need to be loosened in order to attach to the track. If so, loosen the screw with a Phillips screwdriver and if necessary loosen the bolt with the included wrench just enough to slide the Upper Pivot onto track. Tighten Upper Pivot with a Phillips screwdriver as shown in Figure 5.



For 4-Doorset only, replace the Small Spring with the Long Spring in the Snigger as shown in Figure 2.


Note: Insert parts before mounting track to header.



Step 2

Mount Track


Mount Track to header as shown below. From side to side, center the Track in the opening. Use 5EA(max) Long Screws to mount each track. The Upper Pivot should be on the pivoting side of the opening.





Step 3

Mount Hinges

Lay Panels side by side on a flat, clean surface as shown in Figure 7. Push the Panels together and mount hinges in pre-drilled pilot holes. Mount Top/Bottom Hinge as shown in Figure 8. Mount Center Hinge at center of door as shown in Figure 9.



Note: Only use screws as shown in figures below and use only pre-drilled pilot holes.



Step 4

Fasten Mount Plates

Fasten Mount Plates as shown below. Mount plates according to the direction of door swing; right swing or left swing as shown in Figures 10 & 11 below. It may be helpful to mark the mount plate holes with a pencil and using a 3/32" drill bit, drill a 1 1/8" deep pilot hole before inserting screws.

Note: Make sure the nylon locking arm is on the back of the door.

FIGURE 10 - Right Swing






FIGURE 11 - Left Swing



Step 5

Hang Doors by Inserting Bolts into Mount Plates


First insert the bolt in the Upper Pivot into the Long Mount Plate and lock into place by rotating the nylon arm as shown in Figures 13 & 14 below. Next, insert the bolt in the roller into the Short Mount Plate and lock the nylon arm.



Step 6

Mount Lower Jamb Pivot

Use a Phillips screwdriver to adjust the Lower Jamb Pivot to the position shown in Figure 15. Mount the Lower Jamb Pivot by placing it directly under the Track on the pivot side as shown in Figures 15 & 16 below. Fasten with 1 EA Long Screw in the slot first to allow adjustment up and down to give clearance between Lower Jamb Pivot and the bottom of the door as shown in Figure 17. Add 2 EA Long Screws to the holes in the Lower Jamb Pivot once adjustments are final.




Step 7

Attach at Bottom Pivot

Attach the Bottom Pivot into the Lower Jamb Pivot as shown in Figure 17 below by depressing the spring-loaded tab on the lower jamb pivot and inserting the tab on the bottom pivot into the hole in the lower jamb pivot.


Note: Make sure and leave 1/8" clearance between the top of the screw head and the bottom pivot for proper operation. (See Step 8, Check Operation, Make Adjustments to adjust clearance.)



Step 8

Check Operation, Make Adjustments


If necessary use the Wrench supplied to adjust the bolts in the Upper Pivot and Roller to assure the BiFold door set is hanging square in the opening. The Lower Jamb Pivot can be adjusted with a Phillips screwdriver. Arrows in Figure 18 below show directions of adjustments.




Step 9

Attach Fascia (& Fascia Block for 4-Door Installs)

For 2-Door Installs : Attach Fascia to Track by removing the tape backing and pushing against track as shown in Figure 19. Cut Fascia to fit if necessary. (Cut with Fascia front up.)



For 4-Door Installs: Attach each Fascia to the upper corner of the Track by removing the tape backing and pushing against track as shown in Figure 20. Cut Fascia s if necessary. (Cut with Fascia front up.) Place Fascia Block over the gap at the center of the opening.



Step 10

Attach The Pull

Attach the Pull to the inside stile of the non-pivoting door panel as shown in Figure 1. Drill a 3/16" (5mm) diameter hole 36" from the bottom of the door and 11/2" from the vertical edge of the stile as shown in Figure 1. Attach the Pull with the Machine Screw as shown in Figure 21 below.

Note: It is best to drill from the front of the door to the back.

