







## 66-120 INCHES CURTAIN ROD INSTRUCTIONS

ONE (1) ROD SET PACKAGE CONTAINS:

3-PIECE ROD SET	FINIALS	BRACKETS	WALL SCREWS	ANCHORS	THUMB SCREWS
 66-120 IN. (168-305CM)	 X 2	 X 3	 X 6	 X 6	 X 3



- 1) GATHER THE FOLLOWING TOOLS: PENCIL, MEASURING TAPE, SCREWDRIVER AND ELECTRIC DRILL.
- 2) POSITION BRACKETS IN A DESIRED LOCATION ABOVE THE WINDOW BY MARKING WALL SCREW LOCATIONS WITH A PENCIL. BOTH BRACKETS SHOULD BE EQUAL DISTANCE FROM THE OUTSIDE OF THE WINDOW AND THE THIRD BRACKET IN THE CENTER. TIPS: IN MOST SPACES, A CURTAIN ROD SET LOOKS BEST HUNG ON THE WALL OUTSIDE OF THE WINDOW FRAME. ALLOW 1 TO 3 IN (2.5 TO 7.6CM) ON EACH SIDE OF THE WINDOW; 2 TO 4 IN (5 TO 10CM) ABOVE THE WINDOW FRAME.
- 3) IF FIXING TO DRYWALL, CHECK FOR BURIED CABLES AND PIPES BEFORE USING A DRILL BIT. DRILL TO A DEPTH OF 32MM AND INSERT ANCHORS. IF FIXING TO WOODEN BATTEN, NO ANCHORS ARE REQUIRED.
- 4) MOUNT THE BRACKETS WITH THE WALL SCREWS PROVIDED.
- 5) CONNECT THE THREE-PIECE ROD TOGETHER. THE ROD WITH THE SMALLEST DIAMETER IS THE MIDDLE PIECE. REMOVE ALL ATTACHED FINIALS TO FIND THE SMALLER MIDDLE PIECE RESTING INSIDE THE LARGER END PIECE.
- 6) FIT ONE FINIAL TO ONE END OF THE ROD. SLIDE CURTAIN ONTO THE ROD BEFORE FITTING THE OTHER FINIAL.
- 7) PLACE CURTAIN ROD ONTO THE BRACKETS, TIGHTEN THE THUMB SCREWS.