



PEEL & STICK WALLPAPER

INSTALLATION GUIDE

Professional Application for a Refined, Luxurious Finish



OVERVIEW

Our peel and stick wallpaper is designed to be applied to a variety of surfaces, including painted walls, glass, and metal. It is a great way to update your home's decor without the need for a professional installer.



SUITABLE SURFACES

- Smooth, flat wall
- Painted or wall with primer applied, e.g. new plaster



UNSUITABLE SURFACES

- Textured walls including wallpaper, plasterwork or stone or brick
- Glossy or high-gloss finishes (this surface requires pre-treatment, sanding or priming)
- Bare, exposed, untreated wood or stone surfaces



IMPORTANT: This product is designed to be applied to a smooth, flat surface. It is not recommended for use on textured or uneven surfaces.

PREPARATION



1. Clean the surface
Remove dust, grease, and other debris. Lightly sand the surface if necessary. Allow the wall to dry completely.



2. Prime the wall
Apply a coat of primer to the wall. Allow the primer to dry completely.



3. Remove any existing wallpaper
If there is any existing wallpaper, remove it completely. If there is any existing paint, sand it down to a smooth finish.



4. Prime & sand the wall
• Prime the wall
• Sand the wall
• Fill any holes or cracks
• Sand the wall again
• Prime the wall

IMPORTANT: For a truly professional finish, follow the steps in this guide. If you are unsure, please contact our customer service team for more information.

INSTALLATION STEPS

1. Measure & cut



Measure the wall and cut the wallpaper to size. Leave a small overlap at the top and bottom.

2. Peel & stick



Peel the backing off the wallpaper and stick it to the wall. Smooth it down with a roller.

3. Smooth & trim



Smooth the wallpaper down with a roller. Trim the edges with a utility knife.

4. Repeat the process



Repeat the process for the next section of the wall.

5. Final check



Check the wallpaper for any bubbles or wrinkles. If there are any, smooth them out with a roller.

6. Clean up



Clean up any excess wallpaper or adhesive. Dispose of it properly.

FINISHING TOUCHES

- Reattach any loose corners with adhesive
- Repaint any areas that were damaged
- Add a decorative border to the top or bottom



DISCLAIMER

This product is not intended for use on surfaces that are not smooth or flat. It is not recommended for use on surfaces that are not clean or dry.

ITEMS REQUIRED & IMPORTANT NOTES

- Tools & Materials:** Measuring tape, utility knife, roller, primer, sandpaper, adhesive, wallpaper.
- Room Preparation:** Remove any existing wallpaper, paint, or other decorations. Clean the wall thoroughly.
- Wall Surface:** The wall must be smooth, flat, and clean. It must be free of any holes, cracks, or other damage.
- Wallpaper:** The wallpaper must be the correct size and color. It must be free of any wrinkles or bubbles.
- Adhesive:** The adhesive must be the correct type for the wallpaper. It must be applied evenly.
- Roller:** The roller must be the correct size and type. It must be used to smooth the wallpaper down.
- Utility Knife:** The utility knife must be sharp. It must be used to trim the edges of the wallpaper.

THANK YOU FOR CHOOSING OUR PEEL & STICK WALLPAPER. WE HOPE YOU ENJOY THE PROCESS AND THE RESULTS.