

Pod Instruction Sheet

Checklist of Items for Assembly:

- 1.) Slipcover
- 2.) Base

Step 1

Find the back of the slipcover and slip over the back of the chair taking care to line up the seams. (Illustration A)



Illustration A

Step 2

Next pull the cover over the seat portion of the chair, making sure that your corners and seams are all aligned with the edges of the base (Illustration B)



Illustration B

Step 3

At the bottom of the chair, affix the Velcro® piece to the underside of the chair. It may help to rest the back of the chair on the floor so you can easily access the Velcro®. Repeat with remaining sides. (Illustration C)



Illustration C

Step 4

Finish the cover by sliding your hands down the back and tucking the excess between the back and seat adjoining the Velcro® tabs hidden inside (Illustration D). It is easiest to start at the center, working your way to the edges. Reverse these steps to remove the cover for easy care.



Illustration D

