



Remove KD Wrap

KD Brackets Insert onto
Mechanism (after removal of
KD wrap)



After the back is
connected to the base,
connect the power
headrest motor

